

CSiXRevit

SAP2000[°], ETABS[°] and Revit[°] Structure 2014 Data Exchange Documentation







Copyright

Copyright © Computers and Structures, Inc., 2013 All rights reserved.

The CSI Logo[®], ETABS[®] and SAP2000[®] are registered trademarks of Computers and Structures, Inc. Watch & LearnTM is a trademark of Computers and Structures, Inc. Revit[®] is a registered trademark of Autodesk.

The computer program ETABS and SAP2000 and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with Computers and Structures, Inc. Unlicensed use of the program or reproduction of the documentation in any form, without prior written authorization from Computers and Structures, Inc., is explicitly prohibited.

No part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior explicit written permission of the publisher.

Further information and copies of this documentation may be obtained from:

Computers and Structures, Inc. www.csiamerica.com

info@csiamerica.com (for general information)
support@csiamerica.com (for technical support)





DISCLAIMER

CONSIDERABLE TIME, EFFORT AND EXPENSE HAVE GONE INTO THE DEVELOPMENT AND TESTING OF THIS SOFTWARE. HOWEVER, THE USER ACCEPTS AND UNDERSTANDS THAT NO WARRANTY IS EXPRESSED OR IMPLIED BY THE DEVELOPERS OR THE DISTRIBUTORS ON THE ACCURACY OR THE RELIABILITY OF THIS PRODUCT.

THIS PRODUCT IS A PRACTICAL AND POWERFUL TOOL FOR STRUCTURAL DESIGN. HOWEVER, THE USER MUST EXPLICITLY UNDERSTAND THE BASIC ASSUMPTIONS OF THE SOFTWARE MODELING, ANALYSIS, AND DESIGN ALGORITHMS AND COMPENSATE FOR THE ASPECTS THAT ARE NOT ADDRESSED.

THE INFORMATION PRODUCED BY THE SOFTWARE MUST BE CHECKED BY A QUALIFIED AND EXPERIENCED ENGINEER. THE ENGINEER MUST INDEPENDENTLY VERIFY THE RESULTS AND TAKE PROFESSIONAL RESPONSIBILITY FOR THE INFORMATION THAT IS USED.





Introduction

This document describes how to exchange Building Information Modeling (BIM) data between Revit Structure 2014 and ETABS 2013 or later and SAP2000 15.1.0 or later.

This document is divided into two sections. The first section addresses specifics pertaining to data exchange between Revit Structure and ETABS. The second section addresses specifics pertaining to data exchange between Revit Structure and SAP2000.

Data exchange between CSiXRevit and ETABS supports four different workflows:

- 1) Exporting from Revit Structure to create a new ETABS model.
- 2) Exporting from Revit Structure to update an existing ETABS model.
- 3) Importing from ETABS to create a new Revit Structure project.
- 4) Importing from ETABS to update an existing Revit Structure project. In this case, you may choose to only update locations, only update designs, or update both.

Data exchange between CSiXRevit and SAP2000 supports two different workflows:

- 1) Exporting from Revit Structure to create a new SAP2000 model.
- 2) Importing from SAP2000 to create a new Revit Structure project.

The flow of information is idealized in the schematic below:







Revit Structure and ETABS Data Exchange

Data exchange between CSiXRevit and ETABS supports four different workflows:

- 1) Exporting from Revit Structure to create a new ETABS model.
- 2) Exporting from Revit Structure to update an existing ETABS model.
- 3) Importing from ETABS to create a new Revit Structure project.
- 4) Importing from ETABS to update an existing Revit Structure project.

Supported Workflows

Exporting from Revit Structure to create a new ETABS model

The table below provides an overview of the data imported in ETABS when exporting from Revit to create a new ETABS model:

Action	Project Element	Supported	Notes
Creation of			
	Grid Lines		
	Story Levels		
	Materials		
	Structural Columns and		Transfers geometry, offsets, cardinal points,
	Structural Framing		and end releases into ETABS. Imports
			columns based on splice information in ETABS.
	Steel Column and		Creates and maps equivalent ETABS frame
	Framing Family Types		sections. Makes Auto-Select Lists in ETABS for
			all families used in the Revit project.
	Concrete Column		Creates and maps equivalent ETABS frame
	and Framing Family		sections.
	Types		
	Walls		Slanted walls not imported.
	Wall Family Types		Creates and maps equivalent ETABS wall sections.
	Wall Openings		
	Floors		Sloped floors with more than four outer
			corners are projected on a horizontal plane.
	Floor Family Types		Creates and maps equivalent ETABS slab and
			deck sections.
	Floor Openings		



Footings	 Creates fixed joint restraints in ETABS wherever a footing occurs in Revit.
Point Loads	
Line Loads	
Area Loads	Non-uniform area loads not imported.
Load Cases	Creates both an ETABS load pattern and load
	case for each Revit load case.
Load Combos	

Grids

The following Grid attributes are created in ETABS:

- <u>Grid Name</u>: The same grid name is used in the ETABS grid bubble.
- <u>Grid Points</u>: The start and end points are used to define the general grid line in ETABS.
- <u>Curved Grid:</u> The center point, radius, start angle and aperture are used to define the circular grid line in ETABS.

Materials

The following material attributes are created in ETABS:

- <u>Material Name</u>: The same name is used in ETABS.
- <u>Material Type</u>: The Revit material type is used to identify the ETABS material type, namely Concrete, Steel or Other.
- <u>Young's Modulus</u>: The Young's modulus values from Revit set the ETABS material Young's modulus (E). These three values (for the three different directions) cannot be zero in ETABS. If the first value is zero, then the default ETABS value is used. If any of the remaining two are zero, then the first non-zero value is used. For an isotropic material, the first value is used for all other directions.
- <u>Poisson's Ratio</u>: Poisson's Ratio values from Revit set the ETABS material Poisson's Ratio (u). These three values (for the three different directions) cannot be zero in ETABS. If the first value is zero, then the default ETABS value is used. If any of the remaining two are zero, then the first non-zero value is used. For an isotropic material, the first value is used for all other directions.
- <u>Shear Modulus</u>: Shear Modulus value from Revit set the ETABS material Shear Modulus (G). If the Revit material is defined as isotropic, then ETABS calculates this value on the basis of the Young's Modulus and the Poisson's Ratio. In the case of an orthotropic material, these three values (for the three different directions) cannot be zero in ETABS. If the first value is zero, then the default ETABS value is used. If any of the remaining two are zero, then the first non-zero value is used.
- <u>Thermal Expansion Coefficient:</u> The thermal expansion coefficient from Revit sets the ETABS material thermal expansion coefficient (Alpha). These three values (for the three





different directions) cannot be zero in ETABS. If the first value is zero, then the default ETABS value is used. If any of the remaining two values are zero, then the first non-zero value is used. For an isotropic material, the first value is used for all other directions.

- <u>Weight Density and Mass Density</u>: The unit weight value from Revit sets the ETABS material weight density (w) and mass density (m). In ETABS, the mass density is calculated by dividing the weight density by the gravitational constant (g). The weight density cannot be zero in ETABS. If the unit weight is zero in Revit, then the default ETABS densities are used.
- <u>Damping Ratio</u>: This value is not in used in the current version of ETABS.
- <u>Bending Reinforcement:</u> The bending reinforcement value from Revit sets the ETABS material main reinforcement Fy if the type is concrete. If this value is zero in Revit, then the default ETABS value is used.
- <u>Shear Reinforcement:</u> The shear reinforcement value from Revit sets the ETABS material shear reinforcement Fy if the type is concrete. If this value is zero in Revit, then the default ETABS value is used.
- <u>Resistance Calculation Strength</u>: The resistance calculation strength from Revit sets the ETABS material f'c factor. If this value is zero in Revit, then the default ETABS value is used.
- <u>Behavior</u>: The Revit behavior tag is used to identify the isotropic or orthotropic materials in ETABS.
- <u>Concrete Compression</u>: The concrete compression value from Revit sets the ETABS material f'c if the type is concrete.
- <u>Lightweight:</u> The Revit lightweight tag is used to identify the lightweight concrete material in ETABS.
- <u>Shear Strength Reduction:</u> This value is not in used in the current version of ETABS.
- <u>Yield Stress</u>: The yield stress value from Revit sets the ETABS material yielding stress Fy if the type is steel. If this value is zero in Revit, then the default ETABS value is used.
- <u>Tensile Strength</u>: The tensile stress value from Revit sets the ETABS material ultimate stress Fu if the type is steel. If this value is zero in Revit, then the default ETABS value is used.
- <u>Steel Reduction Factor</u>: This value is not in used in the current version of ETABS.

Only those materials linked with floors, walls, or frames in the Revit project are imported into ETABS.

ETABS writes a warning in the .wrn file it writes when a default value is used while importing materials from the Revit project.





Structural Columns and Framing

The following Revit Structure column and framing element attributes are imported into ETABS:

- <u>Frame Curves:</u> Straight framing elements are imported as straight ETABS frame objects. Curved framing elements that are not arc shaped are imported as series of short ETABS objects based on the lines defining their analytical models. Arc shaped framing elements are imported as arc shaped ETABS line objects.
- <u>Frame End Points and Curves:</u> For straight column and framing elements and curved framing elements other than arc shaped, the coordinates of the end points of the lines defining the analytical model of the element are retrieved and ETABS joint objects with identical coordinates are created. When the analytical model of an element includes rigid links, the ETABS joint objects are created at the ends of the rigid links with ETABS joints offsets created to model the link. For arc shaped framing elements, the coordinates of the end points of the elements themselves are imported instead of the end points of their analytical models because these analytical models consist of series of short straight segments and such a tessellation is not required in ETABS 2013. Columns are imported with the Local Axis 1 always pointing up, and beams and braces with their Local Axis 1 always in the first quadrant, which means that the end joints may have been switched compared to the Revit end points. Multi-story columns and braces are automatically broken into several single story ETABS frame objects. This is required for reporting and design.
- <u>Frame Sections:</u> The family type assigned to the Revit element is imported along with the whole family. ETABS converts the Revit family to an ETABS auto selection list.
- <u>End Releases:</u> End releases defined in the element analytical models are imported into ETABS. ETABS restricts releases that would cause an analytical instability, such as for example torsion released at both ends. When that happens, ETABS writes a warning in the .wrn file it writes. When ETABS joints have been switched compared to Revit end points, end releases are also switched.
- <u>Insertion Points</u>: In Revit, the beam insertion point is defined by the following two parameters:
 - Z-Direction Justification
 - Lateral Justification

ETABS calculates the corressponding cardinal point on the basis of these two parameters. If these parameters are not defined for a beam then the default cardinal, Top Center, is chosen. Columns and braces are imported with a Middle Center insertion point.

• <u>End Offsets:</u> When the analytical model of an element includes rigid links, these are imported as end offsets. You can visualize them by looking at the model in extruded view. In addition, when a beam has its z-Direction Justification parameter set to Other, an additional vertical offset is created at both ends of the ETABS frame object based on the value of the z-Direction Offset parameter. Other beam offset parameters such as Start





Level Offset and End Level Offset are not taken into consideration because, except for arc shaped members, end joints are located based on the end points of the analytical model which already reflects the values of these parameters. When ETABS joints have been switched compared to Revit end points, end offsets are also switched.

 <u>Orientation Angles:</u> The ETABS Local Axis 2 Angle of columns is computed based on their rotation as internally stored in Revit Structure. The ETABS Local Axis 2 Angle of beams and braces is computed based on the value of their Cross-Section Rotation parameter. When ETABS joints have been switched compared to Revit end points, rotations are adjusted accordingly.

Frame Sections

The mapping of Revit frame section attributes depends upon their type.

ETABS first tries to find the name of the section in its database. Most steel sections can be mapped automatically. If a section is not found in the database, ETABS tries to create these sections parametrically.

ETABS maps sections through the following steps:

- 1) ETABS first tries to map Revit family sections to the currently loaded ETABS database by comparing section names. If it finds a match then that section is mapped. All geometric cross sectional properties are used from the ETABS section. Blank spaces are always removed and upper/lower cases dissimilarities are ignored when comparing names.
- 2) Next, ETABS tries to map Revit family sections to a section in the ETABS section property files (.XML) by comparing section names. If ETABS finds a section with a matching name, then that section is used along with all its geometric cross sectional properties. In the absence of an exact name match, ETABS looks for a close match where the Revit name contains the ETABS name. The user is given the option to add/remove or change the search order of the property files during the import into ETABS from the Revit project. In Figure 1, "UC356x406x287" section is loaded from "BSShapes.XML".





_	Revit Structure Section	Revit Structure Family	Revit Structure Material	ETABS Section Name	Remarks		Add
98	356x406x287UC	UC-Universal Column-Column	STEEL	UC356X406X287	Section found (imported from BSShapes xml file).	ſ	Eda
99	356x406x340UC	UC-Universal Column-Column	STEEL	UC356X406X340	Section found (imported from BSShapes xml file).		
1	356x406x393UC	UC-Universal Column-Column	STEEL	UC356X406X393	Section found (imported from BSShapes.xml file).		
1	356x406x467UC	UC-Universal Column-Column	STEEL	UC356X406X467	Section found (imported from BSShapes.xml file).	1	
1	356x406x551UC	UC-Universal Column-Column	STEEL	UC356X406X551	Section found (imported from BSShapes xml file).		.XML Hiles
1	356x406x634UC	UC-Universal Column-Column	STEEL	UC356X406X634	Section found (imported from BSShapes.xml file).		
1	300 x 600mm	M_Concrete-Rectangular B	CONC	300 x 600mm	Section created (Revit Structure concrete or wood paramet.		
1	400 x 800mm	M_Concrete-Rectangular B	CONC	400 x 800mm	Section created (Revit Structure concrete or wood paramet.		
1	B500X250	M_Concrete-Rectangular B	CONC	B500X250	Section created (Revit Structure concrete or wood paramet.		
1	B600X300	M_Concrete-Rectangular B	CONC	B600X300	Section created (Revit Structure concrete or wood paramet.		
1	300 x 300mm	M_Concrete-Square-Column	CONC	300 x 300mm	Section created (Revit Structure concrete or wood paramet.		
1	450 x 450mm	M_Concrete-Square-Column	CONC	450 x 450mm	Section created (Revit Structure concrete or wood paramet.		
1	600 x 600mm	M_Concrete-Square-Column	CONC	600 x 600mm	Section created (Revit Structure concrete or wood paramet.	1	
1	750 x 750mm	M_Concrete-Square-Column	CONC	750 x 750mm	Section created (Revit Structure concrete or wood paramet.	£ [OK
1	ConcCol	M Concrete-Square-Column	CONC	ConcCol -	Section created (Revit Structure concrete or wood paramet.	1	Cancel

Figure 1: Import of sections from section property files (.XML files)

C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\AISC14.xml	Add .Pro File
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\AISC14M.xml	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\AusNZv8.xml	Remove .Pro File
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies∖Australia-NewZea ≡	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\BSShapes2006.x	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\ChineseGB08.xm	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\CISC9.xml	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\Euro xml	200
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\Indian.xml	•
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies\SJIJoists.xml	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies Old\AA6061-T6.x	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies Old\AISC.xml	OK
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Librari	ies Old\AISC13.xml 🔻	
	•	Canaal

Figure 2: Adding /Removing XML files when importing into ETABS

- 3) If a Revit Family section cannot be mapped to an ETABS section from any of the property files, then ETABS checks if it is a Revit parametric section. If it is a parametric section, ETABS creates an equivalent section and names it after the Revit family section.
- 4) If a Revit family section is not parametrically defined, then a new ETABS section named after the Revit family section is created with default ETABS section properties. The user has the option to add a new parametric section as a replacement section or to load a





new section from any other section property file(.XML) that is not in the properties file (.XML) list.

5) The user has the option to save a mapping file which can then be reused on subsequent imports. A sample mapping file is shown in Figure 3.

Elle Édit Fgumat View Help ETABS Frame Section Mapping File Total Pro Files = 28 S.NO Pro File Name 1 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 2 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSC14.xml IN USE 3 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSC14.xml IN USE 4 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSTA14-NewZealAnd.xml IN USE 5 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CISC8.xml IN USE 6 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CISC8.xml IN USE 9 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\SIIfofAS.xml IN USE 10 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\SIIfofAS.xml IN USE 11 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.76.xml IN USE 12 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC3.78.ml IN USE 13 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC3.78.ml IN USE 14 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC3.78.ml IN USE 15 C:DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\P	C-S-Roof modified_V13.txt - Notepad	- 0 X
ETABS Frame Section Mapping File * Total Pro Files = 28 * S.MO Pro File Name IN USE 1 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 2 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 3 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\AISSADX8.xml IN USE 4 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\AISSADX8.xml IN USE 5 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\LassADX78.xml IN USE 6 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\LassADX78.xml IN USE 7 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\bin\Debug\Property Libraries\LassADX78.xml IN USE 8 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\LassADX78.xml IN USE 9 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\LassADX78.xml IN USE 11 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\LassADX78.xml IN USE 12 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\SID01ACACSIM 13 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\SID01ACACSIM 14 C: DevelTFS\ETABSV2012. Net2010\CSIETABS\Din\Debug\Property Libraries\SID01ACASC3.x	Eile Edit F <u>o</u> rmat <u>V</u> iew <u>H</u> elp	
Total Pro Files = 28 5.NO Pro File Name 1 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 2 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 3 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 4 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSTA1ia-NewZealand.xml IN USE 5 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSTA1ia-NewZealand.xml IN USE 6 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\Chinese6008.xml IN USE 7 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 8 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 9 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 10 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 11 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 12 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 13 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSIS.xml IN USE 14 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC1.xml IN USE 15 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC1.xml IN USE 16 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.xml IN USE 17 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.xml IN USE 18 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.xml IN USE 21 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.xml IN USE 22 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.xml IN USE 23 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries OId\AISC4.RPD.xml IN USE 24 C: DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Prop	ETABS Frame Section Mapping File	*
28 C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\SECTIONS8.xml IN USE Total Frame Sections = 112 5.N0 Revit Structure Section Name 1 1016x305x249UB UB1016x305x249 2 1016x305x272UB UB1016x305x272 3 1016x305x314UB UB1016x305x314 4 1016x305x349UB UB1016x305x349 5 1016x305x393UB UB1016x305x349 6 1016x305x437UB UB1016x305x437 7 1016x305x487UB UB1016x305x487	Total Pro Files = 28 S.NO Pro File Name 1 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml IN USE 2 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14M.xml IN U 3 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14M.xml IN U 4 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSV8.xml IN U 5 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AUSV8.xml IN U 6 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSShapes2006.xml IN U 7 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CSSS.xml IN USE 8 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CISC9.xml IN USE 9 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CISC9.xml IN USE 9 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\Indian.xml IN USE 10 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries\SIJJoists.xml IN U 11 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.xml IN U 12 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.xml IN U 13 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.xml IN U 14 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.xml IN U 15 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.xml IN U 16 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC1.Xml IN U 17 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC2.xml IN U 18 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISCLRPD.xml IN U 20 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISCLRPD.xml IN U 21 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISCLRPD.xml IN U 22 C:\DevelTFS\ETABSV2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISCLRPD.xml IN	5E 5E 5E 5E 5E 5E 5E 5E 5E 5E
8 127x76x13UB UB127X76x13 9 152x89x16UB UB152x89x16 10 178x102x19UB UB178x102x19 11 203x1325UB UB203x102x23 12 203x133x25UB UB203x133x30 14 254x102x22UB UB254x102x22 15 254x102x25UB UB254x102x22 16 254x102x28UB UB254x102x28 17 254x146x31UB UB254x146x31 18 254x146x37UB UB254x146x37 19 254x146x43UB UB254x146x43	Total Frame Sections = 112 S.NO Revit Structure Section Name 1 1016x305x249UB UB1016x305x272 3 1016x305x272UB UB1016x305x272 3 1016x305x314UB UB1016x305x314 4 1016x305x349UB UB1016x305x349 5 1016x305x437UB UB1016x305x487 6 1016x305x487UB UB1016x305x487 8 127x76x13UB UB105x305x487 8 127x76x13UB UB127x76x13 9 152x89x16UB UB152x89x16 10 178x102x19UB UB178x102x19 11 203x102x23UB UB203x102x23 12 203x133x25UB UB203x133x30 14 254x102x22UB UB254X102x22 15 254x102x25UB UB254X102x25 16 254x102x25UB UB254X102x25 17 254x146x31UB UB254X146x31 18 254x146x43UB UB254X146x37 19 254x146x43UB UB254X146x43	-

Figure 3: Section mapping file

6) Some European family names do not map with the ETABS sections in European properties file (.XML) due to prefix/suffix incompatibility. For Revit Structure families with "Universal Columns" or "Universal Beams" categories, ETABS changes the suffix to prefix when importing.



The parameters list is given for concrete and wood structural families in the following table.

Member Type	Family Name	Parameters
CONCRETE	CONCRETE-RECTANGULAR-	В, Н
COLUMNS	COLUMN	
	CONCRETE-ROUND-COLUMN	В
	CONCRETE-SQUARE-	В
	COLUMN	
	PRECAST-RECTANGULAR	B, H CHAMFER
	COLUMN	
CONCRETE	PRECAST-DOUBLE TEE	WIDTH, TEE WIDTH,
EPAMING		STEM WIDTH, SLAB
FRAMING		DEPTH, DEPTH
	PRECAST-INVERTED TEE	H1, H, B, SEAT
	PRECAST-L SHAPED BEAM	H1, H, B, SEAT
	PRECAST-RECTANGULAR	В, Н
	BEAM	
	PRECAST-SINGLE TEE	WIDTH, STEM
		WIDTH, SLAB DEPTH,
		DEPTH
WOOD	DIMENSION LUMBER-	B, D, SY, SX, IY, IX, A
COLUMNS	COLUMN	
	GLULAM-SOUTHERN PINE-	B, D, SY, SX, IY, IX, A
	COLUMN	
	GLULAM-WESTERN SPECIES-	B, D, SY, SX, IY, IX, A
	COLUMN	
	PSL-PARALLEL STRAND	B, D, SY, SX, IY, IX, A
	LUMBER-COLUMN	
	TIMBER-COLUMN	B, D, SY, SX, IY, IX, A
WOOD	DIMENSION LUMBER	B, D, SY, SX, IY, IX, A
FRAMING		
	GLULAM-SOUTHERN PINE	B, D, SY, SX, IY, IX, A
	GLULAM-WESTERN SPECIES	B, D, SY, SX, IY, IX, A
	LVL-LAMINATED VENEER	B, D, SY, SX, IY, IX, A
	LUMBER	
	TIMBER	B, D, SY, SX, IY, IX, A
	OPEN WEB JOIST	В, Н
	PLYWOOD WEB JOIST	В, Н

Table 1: Parameters used in ETABS





In-place family members

Revit in-place family members are not imported into ETABS.

Walls

The following wall attributes are imported into ETABS:

- <u>Points</u>: The coordinate of all points defined in the wall analytical model are retrieved and ETABS joint objects with identical coordinates are created. Revit walls may be defined as having more than four corners, but ETABS walls can only have three or four nodes. Revit walls with more than four outer corners are broken into several four node walls, with a few three node walls when some of the edges are sloped. Also, multi-story walls are broken into several single story ETABS walls. This is required for reporting and concrete reinforcement design.
- <u>Wall Curve</u>: Arc shaped curved walls with horizontal bases and tops are imported as ETABS curved walls. Straight wall edges are imported as such. Other edges are tessellated, with the degree of approximation defined internally by Revit, and the wall is imported as a series of walls. Note that when a Revit wall is arc shaped in plane but its top is not horizontal, its top curve is not an arc and will be tessellated.
- <u>Wall Openings</u>: Wall openings are imported based on their locations. Opening with more than four corners are broken into three and four node openings. Multi-story openings are broken into several single story openings.
- <u>Wall Thickness</u>: A Revit wall has different layers, each having different thickness and material properties. ETABS only considers the layer with the maximum thickness when importing the data from Revit.
- <u>Wall Materials:</u> All the materials assigned to the different layers of a Revit wall are imported into ETABS. However, only one material is assigned to the ETABS wall section property. Users have the option in ETABS to change the material, if necessary. The material of the wall layer with the maximum thickness is used.

Slanted walls, with their top not lined up with the base when looked at from above, are not imported.

Floors

The following floor attributes are imported into ETABS:

- <u>Floor Points</u>: The coordinate of all points defined in the floor analytical model are retrieved and ETABS joint objects with identical coordinates are created.
- <u>Floor Curves:</u> Floor edges that are arc shaped are imported as arcs in ETABS. Straight floor edges are imported as such. All other curved floor edges are tessellated, with the degree of approximation defined internally by Revit. Floors with more than four outer corners are projected onto a horizontal plane at an elevation matching their average elevation.





- <u>Number of Layers:</u> In Revit, different layers may be defined within a floor. ETABS reads the floor layer information and treats the floor as a **deck** if more than one layer is present in the floor. Otherwise the floor is treated as a **slab**.
- <u>Layer Thickness</u>: ETABS imports the thickness of each layer. If the floor is a **deck**, its section property is defined by the maximum thickness of the layers.

Below is an example of how Revit Deck parameters are mapped to ETABS Deck Section parameters:

Revit Deck Family

	Function	Material	Thickness	Wraps	Structural Material	Variable
1	Core Boundary	Layers Above Wrap	0' 0"			
2	Structure [1]	Concrete - Normal Weight	0' 51/2"		V	
3	Structural Deck [1]	Metal - Deck	0. 0.			
	Insert Delete	<u>U</u> p D <u>o</u> w	n			
struc	tural Deck Properties	Deck Usage				
Deck	FIGHE					





amily: Form Deck_Composite	▼ <u>L</u> oad			
ype: 2" x 6"	▼	te		
ype Parameters	Renam	e		
Parameter	Value	-		
Keynote				
Model				
Manufacturer				
Type Comments				
URL				
Description				
Assembly Description				
Assembly Code				
Type Mark				
Cost		_		
OmniClass Number		=		
OmniClass Title				
Other		*		
wr	0' 21/2"			
rr	0' 1 3/4"			
hr	0' 2"			
Thickness	0' 0 1/32"			
Sr	0' 6"			
		-		





ETABS Deck Section

Property Name	3 1/2" NWC on 2" Met	al De
Туре	Filled	- 0
Slab Material	Concrete - Normal Weig	• • • • • • • • • • • • • • • • • • • •
Deck Material	A992Fy50	▼
Modeling Type	Membrane	-
Modifiers (Currently Default)	Modify/Show	
Display Color	Change	
Property Notes	Modify/Show	
Property Data		
Slab Depth, tc	3.5	in
Rib Depth, hr	2	in
Rib Width Top, wrt	2.5	in
Rib Width Bottom, wrb	1.75	in
Rib Spacing, sr	6	in
Deck Shear Thickness	0.035	in
Deck Unit Weight	2.3	lb/ft²
Shear Stud Diameter	1.75	in
Shear Stud Height, hs	5.4688	in
Shear Stud Tensile Strength, Fu	65000	lb/in²

In this example, there are two layers in the Revit Deck section:

- 1) Concrete Cast-in-Place (Thickness = 5")
- 2) Metal Deck (Thickness = 0)

Layer 2 stands for a deck profile with the following properties:

- HR
- WR
- RR
- SR





• THICKNESS

Here is the procedure CSiXRevit uses to fill ETABS deck section properties:

- The layer with the maximum thickness is selected and treated it as the overall thickness of the section. This layer is used to define the material of the ETABS deck section.
- Slab Depth tc = overall thickness of section HR
- Deck Depth hr = HR
- Rib Width Top wrt = WR
- Rib Width Bottom wrb = RR
- Rib Spacing Sr = SR
- Composite Deck Studs diameter = RR
- Composite Deck Stud height (hs) = overall thickness of section THICKNESS
- <u>Layer Materials</u>: ETABS imports the material of each layer. The material of the thickest layer is assigned to the Slab or Deck section. A default material is used if no material is defined in Revit. Users may later change the material of the different layers as required in ETABS.
- <u>Floor Span Directions</u>: The Revit span direction is imported for decks. A default direction is used if no span direction is defined in Revit.
- <u>Floor Openings (Regular or Irregular)</u>: Openings defined in Revit by "Modeling>Opening>Vertical Opening" are imported into ETABS. All curves in such openings are converted into a number of smaller segments, which gives the suitable curvature for the area boundary.
- <u>Ramps:</u> All inclined slabs with four nodes are imported as ramp elements in ETABS.

Openings

The following openings are imported into ETABS from Revit Structure:

- Vertical Openings: These are imported as opening in the floors (horizontal planes). For details, please check Openings in Floors.
- Wall Openings: These are imported as openings in the walls (vertical planes). For details, please check Openings in Walls.
- Shaft Openings: These are imported as openings in the floors (horizontal planes). For details, please check Shaft Openings.





Shafts

In Revit, a Shaft Opening is defined as a 3D shaft having upper and lower limits (or offset elevations from upper and lower story levels). In ETABS the shaft is imported as horizontal floor openings at all the story levels that lie between the upper and lower limits of the 3D Shaft.

Footings

The following footing properties are imported into ETABS from Revit Structure:

- <u>Points:</u> All the points defining the shape of the footing are imported. In ETABS all columns that are located in this area are restrained.
- <u>Width, Length and Thickness:</u> For rectangular footings, the width, length and thickness are imported. In this case, ETABS locates all the columns within the rectangular footing area and restrains them.

Note: Only rectangular footings are processed.

Point Loads

The following point load attributes are imported into ETABS from Revit Structure:

- Load Case Name: It sets the corresponding load case name in ETABS.
- <u>Location</u>: It is used to define the point of application of the load.
- <u>Fx, Fy, Fz, Mx, My, Mz</u>: All forces and moments applied in the global direction, in Revit, are transferred in a similar manner into ETABS.

Line Loads

The following line load attributes are imported into ETABS from Revit Structure:

- Load Case Name: It sets the corresponding load case name in ETABS.
- <u>Start and End Point Locations</u>: Used to define the start and end point of the line load. Line loads carrying the gravitational load and overlapping more than one beam are distributed to the corresponding beams in ETABS. In the case of a lateral line load, users must check no line load overlaps more than one beam; otherwise it is not processed in the ETABS analysis.
- <u>Fx, Fy, Fz, Mx, My, Mz</u>: All forces and moments applied in the global direction, in Revit, are transferred in a similar manner into ETABS. A Revit line load which includes more than one of these components is imported as several ETABS line loads because ETABS line loads are mono-directional.



Area Loads

The following area load attributes are imported into ETABS from Revit Structure:

- Load Case Name: It sets the corresponding load case name in ETABS.
- <u>Points</u>: Points are used to define the geometry of the loading area. Curved edges that are arc shaped are imported as arcs. Straight edges are imported as such. Other edges are tessellated, with the degree of approximation defined internally by Revit.
- <u>LoadX, LoadY, and LoadZ</u>: All loads applied in the global direction in Revit are transferred in a similar manner into ETABS.

Non-uniform surface loads are not supported in ETABS and not imported.

Load Cases

The following load case attributes are imported into ETABS from Revit Structure:

- <u>Load Case Name</u>: The same name is used for the ETABS load case name except "Rvt-" is added to the beginning of the name.
- <u>Load Case Category:</u> It is used to define the load case type in ETABS. The mapping is shown in the following table:

Revit Structure Load Case Category	ETABS Load Case Type
Dead	Dead
Live	Live
Wind	Wind
Snow	Snow
Roof Live	Live
Accidental	Other
Temperature	Other
Seismic	Quake

Load Combos

The following load combination attributes are imported into ETABS from Revit Structure:

- <u>Load Combination Name</u>: The same name is used for the ETABS Load Combination Name. The following names are reserved and the corresponding Load Combinations will not be added in ETABS if these names are used in Revit:
 - o DCON
 - o DSTL
 - o DWAL
 - DCMPC
 - DCMPS
 - o DCMPD





- Load Cases: The same load cases list is used in ETABS to define the Load Combination.
- <u>Load Case Factor</u>: The same load case factors are used for the corresponding load cases in the ETABS load combination.

ETABS Auto Select Lists

ETABS automatically creates Auto-select lists based on Revit family types that are loaded in the current Revit project and being exported into ETABS.





Exporting from Revit Structure to update an existing ETABS model

The table below provides an overview of the data imported in ETABS when exporting from Revit Structure to update an existing ETABS model:

Action	Model Element	Supported	Notes
Creation of			
	Grids		
	Story Levels		
	Materials		Creates equivalent ETABS materials.
	Frames		Transfers geometry, offsets, cardinal points, and end releases into ETABS. Cuts all columns at story levels.
	Frame Sections		
	Steel Sections		Maps to ETABS database sections.
	Concrete Sections		Creates and maps equivalent ETABS sections.
	Walls		
	Wall Properties		
	Wall Openings		
	Floors		
	Slabs Properties		
	Deck Properties		
	Floor Openings		
	Footings		Creates fixed joint restraints in ETABS wherever a footing occurs in Revit.
	Joint Loads		
	Frame Loads		
	Shell Loads		
	Load Cases		
	Load Combos		
Update of			
	Grids		
	Story Levels		
	Materials		
	Frames		
	Frame Sections		



	Steel Sections	
	Concrete Sections	
	Walls	Walls with changing number of sides are replaced.
	Wall Properties	
	Wall Openings	Wall openings with changing number of sides are replaced.
	Floors	
	Slabs Properties	
	Deck Properties	
	Floor Openings	Floor openings with changing number of sides are replaced.
	Point Loads	
	Line Loads	
	Area Loads	
	Load Cases	
	Load Combos	
Deletion of		
	Grids	
	Story Levels	
	Frames	
	Walls	
	Wall Openings	
	Floors	
	Floor Openings	
	Footings	
	Point Loads	
	Line Loads	
	Area Loads	
	Load Cases	
	Load Combos	

IMPORTANT NOTE: Deletion of elements when updating a model only works if you are sending the ENTIRE model. If the "selection only" update feature is used, deletion of items is not supported.





Importing from ETABS to create a new Revit Structure Project

The table below provides an overview of the data imported in Revit Structure when creating a new Revit Structure project:

Action	Model Element	Supported	Notes
Creation of			
	Grids		
	Story Levels		
	Materials		Imports Concrete and Steel materials into Revit from ETABS. Limitation is the Revit project should have one default concrete and one default steel material for duplication, otherwise the material will be created in Revit but its parameters will not be updated, and the properties of the new materials are identical to those of the template materials.
	Frames		Imports steel columns based on splice locations in ETABS.
	Frame Sections		
	Steel Sections		
	Concrete Sections		Creates and maps equivalent Revit sections. See mapping below.
	Walls		Slanted walls not imported.
	Wall Properties		
	Wall Openings		
	Floors		
	Slabs Properties		
	Deck Properties		
	Footings		
	Load Cases		
	Joint Loads		
	Frame Element Loads		Creates equivalent Revit point line loads and trapezoidal line loads.
	Shell Member Loads		Creates equivalent Revit area loads.
	Load Combos		



Mapping of ETABS section types to Revit families:

Columns

ETABS	Revit Family
Rectangular	Concrete-Rectangular-Column.rfa
Square	Concrete-Square-Column.rfa
Circular	Concrete-Round-Column.rfa

Beams and Braces

ETABS	Revit Family
Rectangular	Concrete-Rectangular Beam.rfa
L	Precast-L Shaped Beam.rfa
Т	Precast-Single Tee.rfa
Steel Plate	Plate.rfa
Steel Rod	Round Bar.rfa





Importing from ETABS to Update an Existing Revit Structure Project

The table below provides an overview of the data imported in Revit Structure when updating an existing Revit Structure project:

Action	Model Element	Supported	Notes
Creation of			
	Grids		
	Story Levels		
	Materials		
	Frames		
	Frame Sections		
	Steel Sections		
	Concrete Sections		Creates and maps equivalent Revit sections. See mapping at end of previous section.
	Walls		
	Wall Properties		
	Wall Openings		
	Floors		
	Slabs Properties		
	Deck Properties		
	Floor Openings		
	Footings		
	Load Cases		
	Joint Loads		
	Line Loads		
	Area Loads		
	Load Combos		
Update of			
	Grids		
	Story Levels		
	Materials		
	Frames		Updates changes to column locations only for columns not meshed in ETABS and with a 1:1 correspondence between Revit and ETABS. You can choose between leaving columns meshed in ETABS in their original Revit locations or replacing them with the ETABS meshed columns.
	Frame Sections		
	Steel Sections		



	Concrete Sections	Updates Beam, Column and Brace section
		assignments; however section parameters
		themselves do not update. If you would like to
		bring in the changes to the parameters from
		ETABS, create a new section with the desired
		parameters in ETABS and assign the new section
		to the frame.
	Walls	Updates changes in wall location only for walls
		not meshed in ETABS and with a 1:1
		correspondence between Revit and ETABS. You
		can choose between leaving walls meshed in
		ETABS in their original Revit locations or replacing
		them with the ETABS meshed walls.
	Wall Properties	Updates wall type assignments; however wall
		types themselves do not update. If a wall section
		is changed in ETABS, it is imported under a new
	Wall Openings	name in Revit.
		Non-rectangular wall openings are not updated.
	FIDUIS	when brought in from ETAPS, and with a 1:1
		when brought in none ETABS, and with a 1.1
		correspondence between leaving floors meshed in
		ETARS in their original Revit locations or replacing
		 them with the FTARS meshed floors
	Slabs Properties	
	blabstroperties	 Updates floor type assignments; however floor
	Deck Pronerties	types themselves do not update. If a floor section
	Deck roperties	name in Povit
	Eloor Openings	Floor openings moved in FTARS are replaced
	Load Cases	
	Point Loads	
	Line Loads	
	Area Loads	Area loads moved in ETABS are replaced.
	Load Combos	- · · · · · · · · · · · · · · · · · · ·
Deletion of		
	Grids	
	Story Levels	
	, Materials	
	Frames	
	Walls	
	Wall Openings	Non-rectangular wall openings are not deleted.
	Floors	
	Floor Openings	Floor openings imported as a floor shaft and





	deleted in ETABS are not deleted.
Load Cases	
Point Loads	
Line Loads	
Area Loads	
Load Combos	

IMPORTANT NOTE: Deletion of elements when updating a model only works if you are sending the ENTIRE model. If the "selection only" update feature is used, deletion of items is not supported.





Procedures

Exporting from Revit Structure to Create/Update a New/Existing ETABS Model

IMPORTANT NOTE: CSiXRevit only exports the analytical model of Revit Structure. All connectivity must be ensured in the Revit Structure analytical model before exporting to ETABS to ensure connectivity.

The following steps describe how to send your Revit Structure analytical model to ETABS:

- To create a new ETABS model, from the Revit menu select, Tools>External Tools>Export to Create New ETABS or SAP2000 Model. To update an existing ETABS model, from the Revit Structure menu select, Tools>External Tools>Export to Update Existing ETABS Model.
- 2. CSiXRevit counts the objects in the Revit project and displays the Export to Create New ETABS or SAP2000 Model dialog, or Export to Update Existing Model dialog as may be the case:

bout	
Select Objects to Export to E	TABS/SAP2000
📝 Grids (6)	No Point Loads
📝 Frames (58)	No Line Loads
📝 Walls (1)	No Area Loads
📝 Floor Slabs (2)	No Load Combos
🔲 No Footings	
Revit Structure Selecte	ed Objects Only

Select the types of elements to send to ETABS. If you have selected some objects prior to starting the command and wish to only export those objects, check the corresponding box at the bottom of the dialog.

Once you have made your selections, click OK.





The Exporting to Create New ETABS or SAP 2000 Model or Exporting to Update Existing ETABS model information message box is shown and displays the progress of the export:



- 3. Once the process has run its course, click OK. You are now asked to select a file name. The file will be given the extension .EXR.
- 4. Start ETABS if it is not already running.
- 5. To create a new ETABS model from your Revit project, you should not have any other model open. By default ETABS creates a new model based on your .EXR file. To update an existing ETABS model, open it.
- 6. From the menu, select File>Import>Revit Structure .exr file, and then select the .EXR file to import. If you are creating a new model, this command is available from the ETABS Start Page. The Revit Data Overview/Controls dialog is displayed:





Data Overview		
Total Levels = 8		Edit
Total Materials = 4		Edit
Total Frame Sections = 175		Edit
Total Floor Sections = 2		Edit
Total Wall Sections = 0		Edit
Controls	22	
Length Units	in	
Length Tolerance	0.1	Import Mapping
Minimum Curve Length	10	ОК
Minimum Curve Angle	3	Casad

The top section of this dialog displays and organizes how all the Revit elements are mapped into ETABS elements.

Any property that may have a default value or zero value displays a warning. Sometimes certain values in Revit were not defined. The ETABS import gives an opportunity to fix these problems parametrically before the ETABS model is created. These problems can be fixed by clicking the "Edit" button next to element.

The bottom section of this dialog displays general controls that ETABS uses when importing the Revit project. The units selected here are used as the default units of the ETABS model. The length tolerance is the tolerance ETABS uses to create connectivity when creating the finite element model for analysis. The Minimum Curve Length and Angle allow the user to control how a curve is divided into straight line segments.

7. To see the various Levels brought in from Revit click the Show button. Level data is not editable at this stage. Level data can be edited once the model is brought into ETABS. Below is a screen shot of all of the levels imported in this model:





	Story	Height ft	Elevation ft	Master Story	Similar To	Splice Story	Splice Height ft
•	Тор	0.3333	36	No	None	No	0
	STORY 3 FRAMING	12	35.6667	No	None	No	0
	STORY 2 FRAMING	12	23.6667	No	None	No	0
	STORY 1 FRAMING	11.6667	11.6667	No	None	No	0
	Base		0				
Note:	Right Click on Grid for Option	ış					

8. To see the Revit material properties imported, select the "Edit" button next to "Total Materials". The Material Mapping dialog is displayed:

	RevitStructure	ETABS	Add
1	Metal - Steel - ASTM A992	Metal - Steel - ASTM A992	Edit
2	Metal - Steel - ASTM A500 - Grade B - Rectangular an	Metal - Steel - ASTM A500 - Grade B - Rectangular an	
3	Concrete - Cast-in-Place Concrete	Concrete - Cast-in-Place Concrete	Revit Data
4	Concrete - Normal Weight - 4 ksi	Concrete - Normal Weight - 4 ksi	
			ОК

In this model four materials are imported. Any new ETABS material is created with the same name as the Revit material name. To map the Revit Structure Material to something other than the new ETABS material created, click on the ETABS material name. A combo box will be displayed with all of the existing ETABS materials currently in the ETABS model. To create a new material property





to map your Revit material to, click "Add". The ETABS Add Material dialog is then displayed. To see the mapping of material parameters select the Material property and click "Edit". The ETABS Material Property Data dialog is then displayed:

Material Name Met		
	tal - Steel - ASTM A992	
Material Type Ste	el	•
Directional Symmetry Type	tropic	•
Material Display Color	Change	
Material Notes	Modify/Show Notes	
Material Weight and Mass		
Specify Weight Density	Specify Mass Density	
Weight per Unit Volume	490.01	lb/ft³
Mass per Unit Volume	15.218	lb-s²/ft⁴
Mechanical Property Data		
Modulus of Elasticity, E	29000122.62	lb/in²
Poisson's Ratio, U	0.29	
Coefficient of Thermal Expansion, A	0.0000065	1/F
Shear Modulus, G	11240357.6	lb/in²
Design Property Data		
Modify/Show Material	Property Design Data	
Advanced Material Property Data		
Nonlinear Material Data	Material Damping Pr	operties
Time Depend	lent Properties	

To check the original properties of the material in Revit, click "Revit Data..." The original properties are displayed:

Weight per Unit Volume	490.01	lb/ft ³
Mass per Unit Volume	15.218	lb-s²/ft⁴
lechanical Property Data		
Modulus of Elasticity, E	29000122.62	lb/in²
Poisson's Ratio, U	0.29	
Coefficient of Thermal Expansion, A	0.000065	1/F
Shear Modulus, G	11240357.6	lb/in²





	Revit Structure Section	Revit Structure Family	Revit Structure Material	ETABS Section Name	Remarks	*	Add
1	BCG W8X67	BCG W-Wide Flange	Metal - Steel - ASTM A	W8X67	Section found (imported from AISC14 xml file).	=	Edit
2	BCG W10X12	BCG W-Wide Flange	Metal - Steel - ASTM A	W10X12	Section found (imported from AISC14 xml file).		
3	BCG W10X15	BCG W-Wide Flange	Metal - Steel - ASTM A	W10X15	Section found (imported from AISC14.xml file).		
4	BCG W12X19	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X19	Section found (imported from AISC14 xml file).		VIII DI
5	BCG W12X22	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X22	Section found (imported from AISC14.xml file).		.XML Hiles
6	BCG W12X26	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X26	Section found (imported from AISC14 xml file).		
7	BCG W12X30	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X30	Section found (imported from AISC14.xml file).		
8	BCG W12X40	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X40	Section found (imported from AISC14 xml file).		
9	BCG W12X50	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X50	Section found (imported from AISC14 xml file).		
10	BCG W12X58	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X58	Section found (imported from AISC14 xml file).		
11	BCG W12X79	BCG W-Wide Flange	Metal - Steel - ASTM A	W12X79	Section found (imported from AISC14 xml file).		
12	BCG W14X22	BCG W-Wide Flange	Metal - Steel - ASTM A	W14X22	Section found (imported from AISC14 xml file).		
13	BCG W14X48	BCG W-Wide Flange	Metal - Steel - ASTM A	W14X48	Section found (imported from AISC14.xml file).		
14	BCG W14X61	BCG W-Wide Flange	Metal - Steel - ASTM A	W14X61	Section found (imported from AISC14 xml file).		OK
15	BCG W16X26	BCG W-Wide Flange	Metal - Steel - ASTM A	W16X26	Section found (imported from AISC14 xml file).	-	Cancel

9. To see the Revit Frame Sections imported, select the "Edit" button next to "Total Frame Sections". The Frame Section Mapping dialog is displayed:

The first three columns display the Revit section name, the Revit Section Family Name, and the Revit Material. The fourth column is the ETABS section the Revit Section is mapped to. The final column describes how the section is mapped or created.

Only the ETABS Section Name column is editable. Clicking any row in the column displays a combo box that includes all section properties currently loaded in the current ETABS model. To add a section to the list, click the "Add" button the right side.

When ETABS imports the Revit data, it initially tries to match Revit section names to ETABS section names. It first searches through the loaded ETABS database sections. If not matched, it then searches all the ETABS section property files (.XML). It will map the section to the first section name that matches. To specify which files are searched, click the ".XML Files" button on the right side. The XML Property Files dialog is displayed:





C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14.xml		Add File
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AISC14M.xml		
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\AusNZv8.xml		Remove File
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\Australia-New2	lea E	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\BSShapes200	6x	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\ChineseGB08:	m í	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\CISC9.xml		
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\Euro.xml		
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\Indian.xml		+
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries\SJIJoists.xml	ા	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AA6061-T	5x	
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC.xml		OK
C:\DevelTFS\ETABSv2012.Net2010\CSIETABS\bin\Debug\Property Libraries Old\AISC13.xm	- ·	
	• 1	Cancel

All the XML property files present in the ETABS installation directory are selected by default. A file can be added or removed from the ETABS search by checking or unchecking its checkbox in the list. To add a new file, click on the "Add File" button. To change the order in which ETABS searches the files, move their names up and down in the list using the arrow key buttons on the right side.

If ETABS cannot create a section mapping by name, it tries to create the section parametrically. For most steel sections ETABS is able to find a match. For concrete sections, ETABS will create the sections parametrically. To see how Revit sections properties are mapped, see the section under "Supported Workflows" called "Exporting from Revit Structure to create a new ETABS model".

Similar to the Material Mapping, details about the Frame Section Mapping can be edited by selecting the row, and clicking the "Edit" button.

To save the mapping created, the mapping file can be exported by clicking the "Export Mapping File" button.

Likewise, to import a mapping file created in the past, click the "Import Mapping File" button.

10. To see the Revit floor sections imported, select the "Edit" button next to "Total Floor Sections". The Floor Section Mapping dialog is displayed:





	Revit Structure Floor Section	ETABS Floor Section	Add Slab
1	12" Concrete	12" Concrete	Add Deck
2	3 1/2" NWC on 2" Metal Deck	3 1/2" NWC on 2" Metal Deck	
			ОК

Similar to other section mapping, you can specify the ETABS floor section the Revit floor gets mapped to. By default an equivalent ETABS floor section is created and mapped. Create a new deck or slab section by using the buttons on the right side. After adding the deck or slab, the new ETABS floor section will show up in the drop down list.

To review the details of an ETABS section, click on the row and then click the "Edit..." button. You will see the Floor Section Mapping Details dialog:

General Data	
Property Name	12" Concrete
Slab Material	Concrete - Cast-in-Place Concret 💌 🛄
Modeling Type	Shell-Thin 🔹
Modifiers (Currently Default)	Modify/Show
Display Color	Change
Property Notes	Modify/Show
Thickness	12 in
Property Data	




Change any of the data in the fields by editing them on the left side and seeing how the data is mapped.

11. To see the Revit wall sections imported, select the "Edit" button next to "Total Wall Sections". The Wall Section Mapping dialog is displayed:

	Revit Structure Wall Section	ETABS Wall Section	Add
1	Generic-12"	Generic-12"	
2	Generic-6"	Generic-6"	Edit
			ОК

Similar to other section mapping, select the ETABS wall section to view the Revit wall it is mapped to. By default an equivalent ETABS wall section is created and mapped. To create a wall section use the "Add" buttons on the right side. After adding the wall, the new ETABS wall section shows up in the drop down list.

To see the Wall Section Mapping details, click on the row and then click the "Edit..." button. You will see the Wall Section Mapping Details dialog:

	Revit Structure Wall Section	ETABS Wall Section	Add
1	Generic - 12"	Generic - 12"	Edit
2	Generic - 6"	Generic - 6"	





Change any of the data in the fields by editing them on the left side and seeing how the data is mapped. Revit walls can have many layers. ETABS does it best at mapping the parameters.

12. Once satisfied with the mapping parameters, in the Revit Data Overview/Controls dialog select OK. The ETABS model is created.





Exporting from ETABS to Create/Update a New/Existing Revit Structure Project

IMPORTANT NOTE: Before importing any .EXR file into Revit Structure be sure you have a Shared Parameter file defined in Revit Structure. CSiXRevit uses the Shared Parameter file as a place to store pertinent data. To create a shared parameter file in Revit Structure2014, go to File>Shared Parameters. You just need to create a blank shared parameter file so CSiXRevit has a place to write data to.

The following steps describe how to export your ETABS analytical model to create or update a Revit Structure project:

- 1. Once you have edited, analyzed and designed your structure in ETABS, save the ETABS file by selecting the File>Save.
- 2. In ETABS, select File>Export>**Revit Structure .exr File** and specify a file name in the Export ETABS-Revit Structure Exchange File dialog which is displayed.
- 3. If you have selected parts of the model, and would like to send only those selections, select the appropriate box:

ETABS
Export only the selected objects?
Yes <u>N</u> o Cancel

- 4. Start Revit Structure.
- 5. To create a new Revit project from your ETABS model, open a Revit template that you would like to import your ETABS model into. It isn't required, but the import will come in faster and will be more predictable if you load all the beam, column, brace, deck, slab and wall families you would like ETABS sections to map to prior to importing. From the menu select, Tools>External Tools>Import to Create New Revit Structure Project from ETABS or SAP2000. Select the .exr file you would like to import. CSiXRevit will try to load families that are not already loaded.

To **update** an existing Revit project, first open it. Again, if you have new sections you defined in ETABS, the import will come in faster and will be more predictable





if you load all the beam, column, brace, deck, slab and wall families you would like ETABS sections to map to prior to importing. From the Revit menu select, Tools>External Tools>Import to Update Existing Revit Structure Project from ETABS. Select the .exr file to import.

6. Whether creating a new Revit project or updating an existing Revit project, after selecting the .EXR file, the following dialog is displayed:

ut				
elect Objects Grid Lines (28) Frames (596)	Point Loads Line Loads	Column Columns present in ETABS/SAP2000 model = 212 Columns present in Revit Structure Project = 0 Delete columns in project and create new instances which were meshed in ETABS model		
v waiis (18) ▼ Floor Slabs (5) ▼ Openings (12)	Area Loads (5) Load Combos	Structural Framing Beam/Braces present in ETABS/SAP2000 model = 384 Beam/Braces present in Revit Structure Project = 0 Delete beams/braces in project and create new instances which were meshed in ETABS model		
apping Options Frame Sections Floor Sections	Wall Sections	Floor Floors present in ETABS/SAP2000 model = 5 Floors present in Revit Structure Project = 0 Delete floors in project and create new instances which were meshed in ETABS model		
formation to Update	t IS	Wall Walls present in ETABS/SAP2000 model = 18 Walls present in Revit Structure Project = 0 Delete Walls in project and create new instances which were meshed in ETABS model		

On the left side, you can control the types of ETABS elements to import into the Revit Structure project and the mapping of ETABS sections to Revit types.





Clicking the "Frame Sections" button under "Mapping Options" displays the Frame Section Mapping dialog:

E1765/374 2000 Section	Revit Structure Family Name	Revit Structure Family Type
450mm	Concrete-Round-Column	450mm
750mm	Concrete-Round-Column	750mm
HSS114.3X8.6	Pipe-Column	HSS114.3X8.6
UC356X368X129	UC-Universal Column-Column	356x368x129UC
Beam Mapping		
ETABS/SAP2000 Section	Revit Structure Family Name	Revit Structure Family Type
300 x 600mm	Concrete-Rectangular Beam	300 x 600mm
400 x 800mm	Concrete-Rectangular Beam	400 x 800mm
600 x 900	Concrete-Rectangular Beam	600 x 900
HSS114.3X8.6	HSS-Round Structural Tubing	HSS114.3X8.6
•		•
Brace Mapping		
ETABS/SAP2000 Section	Revit Structure Family Name	Revit Structure Family Type
HSS114.3X8.6	HSS-Round Structural Tubing	HSS114.3X8.6

Changes to the mapping of ETABS sections to Revit sections can be made here. All Revit column beam and brace families currently loaded are displayed in the drop down lists.





Clicking the "Floor Sections" button displays the "Floor Section Mapping" dialog:

C/i Flo	por Section Mapping		×
	ETABS/SAP2000 Section	Revit Structure Section	
	Generic Concrete 300mm	Create Revit Structure equivalent	-
	160mm Concrete With 50mm Metal D	160mm Concrete With 50mm Met	-
	Generic 300mm	Generic 300mm	•
	Concrete Deck - Tapered Insulation	Create Revit Structure equivalent	-
		Lancei	

Changes to the mapping of ETABS floor sections to Revit sections can be made here. All Revit floor families currently loaded are displayed in the drop down lists.

C/i W	all Secti	ion Mapping		×
		ETABS/SAP2000 Section	Revit Structure Section	
	•	Exterior - 300mm Concrete	Exterior - 300mm Concrete	-
		OK	Cancel	

Clicking the "Wall Sections" button displays the "Wall Section Mapping" dialog:

Changes to the mapping of ETABS wall sections to Revit sections can be made here. All Revit wall families currently loaded are displayed in the drop down lists.





If you are updating a Revit Structure project from an ETABS model, you have the choice to only update locations and releases, only update designs and load magnitudes, or update both:

out				
Select Objects to Update	Column			
☑ Grid Lines (27)	Columns present in ETABS model = 213	Columns present in Revit Structure Project = 203		
Frames (597) Line Loads	Delete columns in project and create new ins	Delete columns in project and create new instances which were meshed in ETABS model		
📝 Walls (18) 🛛 📝 Area Loads (5)				
✓ Floor Slabs (5)	Structural Framing	Structural Framing		
📝 Openings (12)	Beam/Braces present in ETABS model = 384	Beam/Braces present in Revit Structure Project = 397		
Revit Structure selected objects only	Delete beams/braces in project and create n	ew instances which were meshed in ETABS model		
Mapping Options	Floor			
Frame Sections Wall Sections	Floors present in ETABS model = 5	Floors present in Revit Structure Project = 5		
Floor Sections Objects	Delete floors in project and create new instar	nces which were meshed in ETABS model		
Information to Update	Wall			
Cocations and Releases	Walls present in ETABS model = 18	Walls present in Revit Structure Project = 6		
Designs and Magnitudes	Delete Walls in project and create new instar	Delete Walls in project and create new instances which were meshed in ETABS model		
Ø Both				

Also, when updating a Revit project from an ETABS model, there can be instances in which the 1:1 mapping of Revit elements to ETABS elements is lost because elements in ETABS were meshed. If this is the case, you have two options:

- 1. Delete the existing Revit elements, and have CSiXRevit create new instances that are meshed in ETABS.
- 2. Keep the existing elements as they are and use object mapping to control the assignment of section properties during the import.

In the case of option #2, there can be situations in which the user has to make some decisions. For example, if a column in Revit Structure runs from the ground floor to the top floor as a single element, when imported into ETABS, the column is cut at every floor level. When it is designed, different sections might be assigned to each segment of the column. When the column (that is now meshed in ETABS) is imported back into Revit, you have the option to 1) delete the original column in Revit and have CSiXRevit create a column with the varying sections or to 2) select one of the frame sections for the entire length of that column. This can be accomplished by selecting the corresponding checkbox and





clicking the "Objects" button under Mapping Options. The "Object Mapping" dialog is displayed:

Select Object Ty	ре			
Columns	🔘 Beams	🔘 Braces	Floors	🔿 Walls
Revit Structure C	Object List			
Column ID(13	9774)			
ETABS Sections	List (Meshed ob	jects)		
W14X68				
- W14045				
-				
		e hraken into 3 lir	ne objects.	
escription: Colum	n ID(139774) wa	S DIOKETTITILO J III		
escription: Colum nese line objects /14X109' section	n ID(139774) wa have 3 different will be used to u	sections. pate Column ID(139774).	

In this case, Column ID (139774) spans three floors in Revit but was meshed into three pieces in ETABS. When coming back into Revit, the user has the option to choose which section to assign to the entire length of the column. The same methodology can be applied to meshed beams, braces, floors and walls.

Once satisfied with the object mappings, select OK and your ETABS model will be imported.





Reviewing the Log File (.log)

Every time a model is sent from Revit Structure to ETABS or from ETABS to Revit Structure, a file with the extension *.log* is created if it does not exist, or appended if it already exists. This file lists the project or model name, the workflow operation, and the time and date. It also lists any errors or omissions encountered in generating or importing the .EXR file, and therefore, should be checked every time data is transferred. The .log file also lists the build numbers for CSiXRevit and Revit Structure. The two should be identical to ensure no misinterpretation of data occurred. The first few lines of the .log file have the following format (the actual data may be different):

CSiXRevit Revit API Build = 20130308_1515 Current Revit Version = 2014 Current Revit Build = 20130308_1515

The "Build =" numbers should be the same – having the same Version numbers but different Build numbers does not guarantee data consistency.

Finally, in the case of an incremental import, the changes made to the Revit project are listed.

Added Area Load for the following elements: 262405 to replace 262161 262422 to replace 262188 262439 to replace 262205 262456 to replace 262222 262473 to replace 262239 262490 to replace 262256

Added Floor for the following elements: 262383 to replace 262086 262393 to replace 262117 262401 to replace 262125

Changed Beam camber for the following elements: 262053 to C=1.75" 262056 to C=1.75" 262059 to C=1.75" 262062 to C=1.75" 262065 to C=1.75" 262068 to C=1.75" 262071 to C=1.75" 262074 to C=1.75" 262077 to C=1.75"





Changed Beam end reactions for the following elements: 262053 262056 262059 262062 262065 262068 262071 262074 262077 Changed Beam shear studs for the following elements: 262053 to (20) 262056 to (20) 262059 to (20) 262062 to (20) 262065 to (20) 262068 to (20) 262071 to (20) 262074 to (20) 262077 to (20) Moved Structural Member for the following elements: 261993 by 10.00 ft, 0.00ft 261996 by 10.00 ft, 0.00ft 262000 by 10.00 ft, 0.00ft 262003 by 10.00 ft, 0.00ft 262005 by 10.00 ft, 0.00ft 262008 by 10.00 ft, 0.00ft 262012 by 10.00 ft, 0.00ft 262015 by 10.00 ft, 0.00ft 262017 by 10.00 ft, 0.00ft

262020 by 10.00 ft, 0.00ft

Each Revit element is identified by its "Revit ID". You can view the elements the ids referred to by selecting Manage->Select by ID in the Revit Structure ribbon, typing an id, and clicking the Show button:



.Revit will identify a view that contains the element, switch to that view, and highlight the element.





Known Limitations with CSiXRevit and ETABS

- For Windows with strict UAC (User Account Control), users must "Run as Administrator" (for ETABS.exe and Revit.exe). If Revit Structure is not run as administrator, it is possible CSiXRevit will not be able to open the .log file. In this case, CSiXRevit will not write any warnings to the log file but all warning messages will be displayed on the screen. Directly sending data to ETABS may not work if Revit Structure is not run as administrator.
- 2. Updates to end release conditions in ETABS are not updated in Revit.
- 3. Sometimes updates to cardinal points in ETABS are not updated in Revit Structure because the z-justification and offset parameters are Read-only.
- 4. When importing a new Revit Structure project, only the openings that lie completely within a wall or floor are imported. It is recommended to break any openings not completely inside a wall or floor before importing. Openings not inside any wall or floor cannot be imported into Revit Structure.
- 5. Revit Structure floors that are grouped together may be treated as openings when importing into ETABS.
- 6. It is recommended to avoid double byte characters for Revit Structure Families for entities attached with the analytical model. ETABS does not support double byte characters in frame and shell section names.
- 7. Import of European and Chinese steel sections from Revit Structure to ETABS is possible if their corresponding .PRO files are present in ETABS folder.
- 8. Materials imported into Revit Structure from ETABS may not always be properly mapped or the property values may not always be properly transferred. For this reason, material mapping and material property values should always be carefully checked in Revit Structure after importing from ETABS.





Revit Structure and SAP2000 Data Exchange

Data exchange between CSiXRevit and SAP2000 supports two different workflows:

- 1) Exporting from Revit Structure to create new SAP2000 model.
- 2) Importing from SAP2000 to create a new Revit Structure project.

Supported Workflows

Exporting from Revit Structure to create a new SAP2000 Model

The table below provides an overview of the data transferred from Revit Structure to SAP2000:

Action	Project Element	Supported	Notes
Creation of			
	Grid Lines		Does not transfer.
	Materials		
	Steel		
	Concrete		Does not transfer reinforcement properties.
	Aluminum		Imports as isotropic "Other" SAP2000
	Generic		material type.
	Other		
	Wood		
	Frames		Transfers geometry, cardinal points, and end releases into SAP2000. Ignores end offsets. Imports curved Revit framing as a series of short straight SAP2000 frame elements.
	Frame Sections		
	Rolled Steel Sections		Loads equivalent SAP2000 section profiles from the SAP2000 .PRO files specified during import of the .EXR file into SAP2000.
	Bar Joists		Imports with "None" properties.
	Concrete Sections		Creates and maps equivalent SAP2000 sections.
	Walls		Imports walls as SAP000 shell elements with wall openings imported as separate shell elements with "None" properties. Imports curved Revit walls as a series of short planar SAP2000 shell elements.
	Wall Properties		Creates and maps equivalent SAP2000 thick shell sections.



Floors	 Imports floors as SAP000 shell elements with floor openings imported as separate shell
Slabs Properties	Creates and maps equivalent SAP2000 thick shell sections.
Slab on Deck Properties	Creates and maps equivalent SAP2000 thick shell sections with directional stiffness modifiers.
Footings	Does not transfer.
Point Loads	Creates SAP2000 joints if the load does not coincide with a previously created joint and does not line up with any frame elements. This will cause model instability that needs to be addressed.
Line Loads	Creates SAP2000 frame elements with "None" properties if the load does not overlap any other frame element. If the load also does not line up with any imported floor or wall, it will cause model instability that needs to be addressed.
Area Loads	Does not transfer.
Load Cases	
Load Combinations	

Grid Lines

Revit Structure grid lines are not imported in the current version of SAP2000.

Materials

All Revit Structure materials are imported into SAP2000 as isotropic materials. The following Revit material attributes are imported into SAP2000:

- <u>Material Name</u>: The same name is used in SAP2000.
- <u>Material Class</u>: Concrete and steel set to equivalent SAP2000 material types. Generic, aluminum, and wood material types set as "Other" SAP2000 material type.
- <u>Young's Modulus</u>: The first of Revit's three Young's modulus values (one for each direction) sets the SAP2000 material Young's modulus (E) value. If this value is zero, the default SAP2000 value is used.





- <u>Poisson's Ratio</u>: The first of Revit's three Poisson's Ratio values (one for each direction) sets the SAP2000 material Poisson's Ratio (U) value. If this value is zero, the default SAP2000 value is used.
- <u>Shear Modulus</u>: The first of Revit's three Shear Modulus values (one for each direction) is compared to the value of the material Shear Modulus (G) computed by SAP2000. If the two differ by more than one percent in SAP2000, a warning is reported in the log file.
- <u>Thermal Expansion Coefficient</u>: The first of Revit's three thermal expansion coefficients (one for each direction) sets the SAP2000 material thermal expansion coefficient (Alpha). If this coefficient is zero, the default SAP2000 value is used.
- <u>Unit weight:</u> The Revit unit weight sets both the SAP2000 material weight density (w) and mass density (m). In SAP2000 the mass density is calculated by dividing the weight density by the gravitational constant (g). If the unit weight is zero, the default SAP2000 value is used.
- <u>Behavior</u>: Revit uses this tag to distinguish between isotropic and orthotropic materials. All Revit materials are imported as isotropic materials in SAP2000. Any orthotropic material generates a warning in the log file.
- <u>Concrete Compression</u>: In the case of a concrete material, the Revit concrete compression sets the SAP2000 concrete compressive strength f'c.
- <u>Lightweight:</u> The value of this tag is used to identify a concrete material as lightweight concrete in SAP2000.
- <u>Yield Stress</u>: In the case of a steel material, this value sets the SAP2000 minimum yield stress Fy. If the yield stress is zero, the default SAP2000 value is used.
- <u>Tensile Strength</u>: In the case of a steel material, this value sets the SAP2000 minimum tensile stress Fu. If the tensile stress is zero, the default SAP2000 value is used.

The following Revit material attributes are not imported in the current version of SAP2000:

- <u>Damping Ratio</u>
- Bending Reinforcement
- Shear Reinforcement
- <u>Resistance Calculation Strength</u>
- <u>Shear Strength Reduction</u>
- <u>Steel Reduction Factor</u>

Only those materials associated with walls, framing, or floors in the Revit Structure project are imported into SAP2000.

Frames

The following Revit Structure frame member attributes are imported into SAP2000:

• <u>Analytical Model End Points:</u> The point coordinates are used to locate matching joints already created, and when none can be found, create new joints. When importing end





points, SAP2000 views two points as coincident if none of their coordinates differ by more than $1/100^{\text{th}}$ of a foot. This level of precision corresponds to the level of precision in the Revit database.

- <u>Frame Curves:</u> SAP2000 does not support curved frame objects and any curved Revit member is imported as a series of short straight SAP2000 frame elements. Revit controls how the curve is broken into segments.
- <u>Family Type:</u> See Frame Sections below.
- <u>Frame Releases:</u> All frame releases defined in Revit are imported into SAP2000 as line object releases. Releases that cause model instability are restrained and a warning is reported in the log file.
- <u>Beam Insertion Point</u>: In Revit, a beam insertion point is defined by the following two parameters:
 - Z-Direction Justification
 - o Lateral Justification

SAP2000 calculates the coressponding cardinal point on the basis of these two parameters. If these parameters are not defined, then the default cardinal point (middle center) is chosen.

<u>Column Orientation and Beam and Brace Cross-Section Rotation</u>: This angle measures the rotation of the member around its longitudinal axis in Revit and sets the value of the "Rotation about 1" angle in elements imported into SAP2000. The two angles are measured identically in both programs except they differ by 90° in the case of columns.

The following Revit Structure frame member attributes are not imported into the current version of SAP2000:

- <u>Column Beam and Brace Vertical End Offsets:</u> Revit column beams and brace vertical end offsets are not imported into SAP2000 because element end points are retrieved from their Revit analytical models.
- <u>Column Insertion Point</u>: The cardinal point of imported columns is always middle center.
- <u>Rigid Links</u>

Frame Sections

Frame member sections are defined in Revit by their assigned family type.

When reading an .exr file, SAP2000 attempts to match each Revit frame member family type to an identically named section profile defined in the AISC13.pro file (or AISC13M.pro depending on the display unit system in use when importing begins).

In the absence of such a match, SAP2000 checks if the type is from one of the parametric families (Table 2) for which it knows how to generate sections for.

Any frame member type not matched becomes an unrecognized type for which SAP2000 requires additional user input.





This additional input is entered in the Import Revit Structure .exr file dialog displayed when an import into SAP2000 begins. Here all unrecognized types are listed in a table, allowing them to be manually matched to predefined SAP2000 section profile names or, as a last resort, to the SAP2000 "None" property.

Import Revit Structure exr file		×
Select EXR File	:\Samples\Amelia ET.	ABS\model exported from Revit.EXR
928 Frame Elements	Revit Type	SAP2000 Profile
✓ 224 Floors	C150X12 C200X17	C150X10.4
IP6 Point Loads	C230X20	C230X22
I 1697 Line Loads ☐ 324 Area Loads	HS152X152X13 HS152X152X9.5	HSS152.4X152.4X12.7 HSS152.4X152.4X12.7 HSS152.4X152.4X15.9
Import In SAP2000	HS178X178X13 HS178X178X9.5	HSS152.4X152.4X3.2 HSS152.4X152.4X4.8 HSS152.4X152.4X6.4
		HSS152.4X132.4X7.9 HSS152.4X152.4X9.5 HSS152.4X3.2

Here additional section properties databases (.PRO files) can be loaded. When adding a properties file (.PRO), the unrecognized Revit types are checked against the section profile names in this file. This may resolve most of the unrecognized types if the correct properties file (.PRO) is chosen.

SAP2000 saves the properties files (.PRO) manually loaded and the manual assignments made here in a file with an .EXRMap extension. When importing into SAP2000 the same Revit project again, SAP2000 will automatically restore these choices.

When loading an .exr file, SAP2000 keeps track of which materials are used in conjunction with which section profiles. When a section profile is always used with the same material, the corresponding section property is named after the profile. If a section profile is used with a number of different materials, the various corresponding section properties will have compound names consisting of the profile name with the relevant material name appended.





The parameters for concrete and wood structural families are listed in the table below:

Member Type	Family Name	Parameters
CONCRETE	CONCRETE-RECTANGULAR-	В, Н
COLUMNS	COLUMN	
	CONCRETE-ROUND-COLUMN	В
	CONCRETE-SQUARE-	В
	COLUMN	
	PRECAST-RECTANGULAR	B, H CHAMFER
	COLUMN	
CONCRETE	PRECAST-DOUBLE TEE	WIDTH, TEE WIDTH,
EPAMING		STEM WIDTH, SLAB
FRAMING		DEPTH, DEPTH
	PRECAST-INVERTED TEE	H1, H, B, SEAT
	PRECAST-L SHAPED BEAM	H1, H, B, SEAT
	PRECAST-RECTANGULAR	В, Н
	BEAM	
	PRECAST-SINGLE TEE	WIDTH, STEM
		WIDTH, SLAB DEPTH,
		DEPTH
WOOD	DIMENSION LUMBER-	B, D, SY, SX, IY, IX, A
COLUMNS	COLUMN	
	GLULAM-SOUTHERN PINE-	B, D, SY, SX, IY, IX, A
	COLUMN	
	GLULAM-WESTERN SPECIES-	B, D, SY, SX, IY, IX, A
	COLUMN	
	PSL-PARALLEL STRAND	B, D, SY, SX, IY, IX, A
	LUMBER-COLUMN	
	TIMBER-COLUMN	B, D, SY, SX, IY, IX, A
WOOD	DIMENSION LUMBER	B, D, SY, SX, IY, IX, A
FRAMING		
	GLULAM-SOUTHERN PINE	B, D, SY, SX, IY, IX, A
	GLULAM-WESTERN SPECIES	B, D, SY, SX, IY, IX, A
	LVL-LAMINATED VENEER	B, D, SY, SX, IY, IX, A
	LUMBER	
	TIMBER	B, D, SY, SX, IY, IX, A
	OPEN WEB JOIST	В, Н
	PLYWOOD WEB JOIST	В, Н

Table 2: Parameters used in SAP2000





In-place Family Members

Revit Structure in-place family members are not imported into the current version of SAP2000.

Walls

Revit Structure walls are imported into SAP2000 as shell elements. The following Revit Structure wall attributes are imported into SAP2000:

- <u>Analytical Model End Points</u>: The point coordinates are used to locate matching joints already created, and when none are found, create new joints.
- <u>Wall Curves:</u> Curved vertical Revit walls are imported as a series of short planar SAP2000 shell elements. Revit controls how the curve is broken into segments.
- <u>Wall Openings (Regular rectangular shape)</u>: This refers to wall openings drawn with the Revit selection Modeling>Opening>Wall Opening. These openings are imported into SAP2000 as shells element, with "None" properties, that overlap the shell element generated for the wall.
- <u>Wall Thickness and Material</u>: Revit walls may consist of different layers with different thickness and materials. The thickness and material type of the layer with the maximum thickness are used to find or create an appropriate SAP2000 thick shell property. Wall section properties are named after the Revit wall types. The suffix "-WALL" is appended to this name if the name is also used for a floor type.

Floors

Revit Structure floors are imported into SAP2000 as shell elements. The following Revit Structure floor attributes are imported into SAP2000:

- <u>Analytical Model End Points</u>: The point coordinates are used to locate matching joints already created, and when none can be found, create new joints.
- <u>Floor Curves:</u> SAP2000 does not support curved edges in shell elements. All curves in Revit floors are approximated as a series of straight segments. Revit controls how the curve is segmented.
- <u>Floor Thickness and Material:</u> Revit floors may consist of different layers. If there is only one layer, its thickness and material are used to define an equivalent SAP2000 thick shell property. If there is more than one layer, and one of the layers corresponds to a Revit deck profile and at least one other is a concrete layer, SAP2000 creates a concrete thick shell property. Its thickness is equal to the total thickness of all the concrete layers and the membrane and bending stiffness modifiers assigned will account for the presence of deck ribs. Floor section properties are named after the Revit floor types.
- <u>Floor Span Direction</u>: Sets the SAP2000 shell element local axes.
- Inclined Slabs: Also imported into SAP2000 as shell elements.





Openings

Revit Structure openings are imported into SAP2000 as shell elements with "None" properties. This includes:

- Floor Openings
- Wall Openings
- <u>Shaft Openings</u>: These are imported as SAP2000 shell elements located at the base of the shaft with "None" properties.

Footings

Revit Structure footings are not imported in the current version of SAP2000.

Point Loads

The following Revit Structure point load attributes are imported into SAP2000:

- Load Case Name: Sets the load pattern name in SAP2000.
- Location: The point coordinates are used to locate a matching joint already created. SAP2000 views a joints and a point load as coincident if none of their coordinates differ by more than 1/20th of a foot. This level of precision corresponds to the level of precision in the Revit database. When no coincident joint is found, SAP2000 looks for an underlying frame element. If no suitable frame element is found, SAP2000 creates a new joint. This new joint creates model instability that needs to be addressed.
- <u>Fx, Fy, Fz, Mx, My, Mz</u>: All forces and moments are defined in the global coordinates system in Revit and defined in SAP2000 in a similar manner.

Line Loads

The following Revit Structure line load attributes are imported into SAP2000:

- <u>Load Case Name</u>: Sets the corresponding load case name in SAP2000.
- <u>Start and End Point Locations</u>: These define the start and end points of the line load. A line load overlapping more than one frame element is distributed on the corresponding frame elements. If all or part of the load cannot be assigned to frame elements, new frame elements with "None" properties are created. This will cause model instability if the load does not also line up with any imported floor or wall.
- <u>Fx, Fy, Fz, Mx, My, Mz</u>: All forces and moments are defined in the global coordinates system in Revit and defined in SAP2000 in a similar manner.

Area Loads

Revit Structure area loads are not imported in the current version of SAP2000.





Load Cases

Revit Structure load cases are imported into SAP2000 as both load patterns and load cases. One load pattern and one load case are both created in SAP2000 for each Revit load case. The following Revit Structure load case attributes are imported into SAP2000:

- <u>Load Case Name</u>: Sets the corresponding load case name in SAP2000.
- <u>Load Case Category:</u> This defines the load case type in SAP2000. The mapping is shown in the following table:

Revit Structure Load Case Category	SAP2000 Load Case Type
Dead	Dead
Live	Live
Wind	Wind
Snow	Snow
Roof Live	Live
Accidental	Other
Temperature	Temperature
Seismic	Quake

Load Combinations

The following Revit Structure load combination attributes are imported into SAP2000:

- Load Combination Name: The same name is used in SAP200.
- Load Cases: The same load case list is used in SAP2000.
- Load Case Factors: The same load case factors are used in SAP2000.



Importing from SAP2000 to create a new Revit Structure Project

The table below provides an overview of the data transferred from SAP2000 to Revit Structure:

Action	Model Element	Supported	Notes
Creation of			
	Grid Lines		Does not transfer.
	Joints		Does not transfer, but force joint loads transfer.
	Materials (isotropic)		Creates material. Limitation is the Revit project should have one default concrete and one default steel material for duplication, otherwise the material will be created in Revit but its parameters will not be updated, and the property of the new materials are identical to
			those of the template materials.
	Materials (orthotropic)		Does not transfer.
	Frames		
	Vertical Frames		Creates as columns in Revit. Cardinal point, end length offsets and joint offsets do not transfer.
	Horizontal Frames		Creates as beams in Revit. End length offsets and joint offsets do not transfer.
	Other Frames		Creates as braces in Revit. Cardinal point, end length offsets and joint offsets do not transfer.
	Cables		Imports as columns, beams, or braces based on their alignment.
	Frame Sections		
	"None"		Does not transfer frame element.
	Tapered Sections		Does not transfer frame element.
	Steel Sections		Maps to Revit family types with matching names. If not loaded, family type is located and if found, loaded.
	Joists		Maps to Revit family types with matching names. If not loaded, family type is located and if found, loaded.
	Concrete Sections		Creates and maps equivalent Revit sections.
	SAP2000 Auto Select Lists		Does not transfer.
	Shells		
	Vertical Shells		Imports as walls in Revit.
	Horizontal Shells		Imports as floors in Revit.





Shells in other	Imports in Revit as floors with a slope. Slope
planes	value may require user adjustment.
Non-planar shells	Does not transfer.
Shell Properties	
"None"	Does not transfer the shell.
Membrane	Does not transfer stiffness modifiers.
Plate	
Shell	
Layered	Does not transfer.
Planes	
Vertical Planes	Imports as walls in Revit.
Horizontal Planes	Imports as floors in Revit.
Other Planes	Imports in Revit as floors with a slope. Slope
	value may require user adjustment.
ASolids	Does not transfer.
Solids	Does not transfer.
Link/Support	Does not transfer.
Tendons	Does not transfer.
Joint Loads	
Force	Loads defined in coordinate systems other than
	local or global do not transfer.
Displacement	Does not transfer.
Frame Loads	
Concentrated	Loads defined in coordinate systems other than
Distributed	local or global do not transfer.
Temperature	Does not transfer.
Strain	
Target Force	Does not transfer.
Internal Force	
Shell and Plane	
Loads	
Uniform	Loads defined in coordinate systems, other than
Uniform to Frame	local or global do not transfer.
Surface Pressure	
Pore Pressure	Does not transfer.
Temperature	
Strain	
Load Patterns	Imports as Revit load cases, unless their type
	does not correspond to a predefined Revit load
	case category.
Load Cases	





Static Linear	Imports into Revit only if all static linear load cases each refer to a single load pattern. Load patterns not imported into Revit are not included in the list of Revit Structure load cases.
Other than Static Linear	Does not transfer.
Load Combinations	Imports as Revit load combination only if it refers to more than one load pattern. Load patterns not imported into Revit are not included in the list of Revit load cases.

Grid Lines

SAP2000 grid lines are not imported into Revit Structure.

Joints

While model geometry is imported into Revit Structure, SAP2000 joints themselves are not imported. This restriction includes supports.

Materials

CSiXRevit creates Revit Structure materials with the same names as the SAP2000 materials if they are not already in the project template:

- <u>Material Name:</u> The same name is used in Revit.
- <u>Material Type:</u> Concrete and steel set to equivalent Revit material classes. Aluminum, Cold-formed steel and Other set to Revit Generic material class.
- <u>Concrete Compressive Strength</u>: In the case of a concrete material, CSiXRevit attempts to create a new concrete material which duplicates a Revit Structure concrete material with the same concrete compressive strength if it can find one in the project template. If not, a new concrete material is created but its concrete compressive strength differs from the original SAP2000 value.
- <u>Lightweight Concrete</u>: In the case of a concrete material, sets the corresponding Revit attribute.
- <u>Minimum Yield Stress</u>: In the case of a steel material, CSiXRevit attempts to create a new steel material which duplicates a Revit Structure steel material with the same minimum yield stress if it can find one in the project template. If not, a new steel material is created but its minimal yield stress differs from the original SAP2000 value.

Only materials associated with exported SAP2000 frame, cable and shell elements are imported into the new Revit Structure project.





Frame Elements

SAP2000 frame elements are imported into Revit Structure as columns, beams, or braces depending on whether they are vertical, horizontal, or inclined. Frame element with "None" properties, non-prismatic properties, or a material that cannot itself be exported are not imported into Revit Structure. The following SAP2000 frame member attributes are imported into Revit Structure:

- <u>Name</u>: The SAP2000 name is imported into Revit as a shared parameter.
- <u>Start and End Joints:</u> The coordinates of their start and end joints set the end points of the Analytical Models of the new Revit Structure columns, beams, or braces.
- <u>Properties:</u> The name of the SAP2000 properties is exported. When importing frame elements from an .exr file into Revit, CSiXRevit always attempts to locate and load a Revit family type with the same name as the SAP2000 properties name. Note that the search is much quicker if the relevant Revit sections are already loaded in your Revit prototype or project before you import your SAP2000 model. For some concrete frame element properties corresponding to the families listed in Table 2, CSiXRevit creates a new family type, if it is not already in the new Revit project, and another type of the same family, if it is already loaded. Therefore if a SAP model includes concrete frame elements, at least one type of the relevant concrete member families in Revit prototype or project should be loaded prior to import.
- <u>Frame Releases:</u> See Limitations.
- <u>Insertion Point</u>: Only the insertion points of SAP2000 horizontal elements are imported into Revit, as neither Revit columns nor braces have Z-Direction or Lateral Justification attributes.
- <u>Local Axes</u>: Sets Revit Structure Column Orientation and Beam and Brace Cross-Section Rotation.

The following SAP2000 frame element attributes are not imported into Revit Structure:

- Frame Joint Offsets
- End Length Offsets

Cable Elements

SAP2000 cable elements are imported into Revit Structure as columns, beams, or braces depending on whether they are vertical, horizontal, or inclined. Cable element with "None" properties, or a material that cannot itself be exported are not imported into Revit Structure. The following SAP2000 cable element attributes are imported into Revit Structure:

- <u>Name</u>: The SAP2000 name is imported into Revit as a shared parameter.
- <u>Start and End Joints:</u> The coordinates of their start and end joints set the end points of the Analytical Models of the new Revit columns, beams, and braces.





• <u>Properties</u>: The name of SAP2000 properties is exported. When importing cable elements from an .exr files into Revit, CSiXRevit always attempts to locate and load a Revit family type with the same name.

Shell and Plane Elements

SAP2000 shell and plane elements are imported into Revit Structure in different ways based on their orientation. Vertical shell and plane elements are imported into Revit Structure as walls. Horizontal shell and plane elements are imported into Revit Structure as floors. Other planar shells and plane elements are imported into Revit Structure as floors with a slope. Non-planar shell elements, shell and plane elements with "None" properties, or with layered properties, are not imported into Revit Structure. The following SAP2000 shell and plane attributes are imported into Revit Structure:

- <u>Name</u>: The SAP2000 name is imported into Revit as a shared parameter.
- <u>Joints:</u> Their coordinates set the corners of the new Revit wall or floor analytical model. In the case of shell and plane elements that are neither vertical nor horizontal, floors with a slope are created in Revit. Note that while their slope is initially set correctly, Revit subsequently resets it to a different value. The correct slope is available as a shared parameter named "Computed slope" and you need to reset the slope of the floor to this parameter value.
- <u>Properties:</u> SAP2000 shell, membrane, plate, and plane properties are imported into Revit as wall or floor type and as a single layer. The thickness and material matches the SAP2000 thickness and material. Note that stiffness modifiers are not exported.

Solid Elements, ASolid Elements, Link/Support Elements, Tendon Objects

SAP2000 Solid Elements, ASolid Elements, Link/Support Elements, and Tendon Objects are not imported into Revit Structure.

Force Joint Loads and Frame Element Concentrated Loads

SAP2000 force joint loads and frame element concentrated loads are imported into Revit Structure as point loads. Not all force joint loads are imported: see Load Pattern and Coordinate System below. The following SAP2000 force joint load attributes are imported into Revit Structure:

- <u>Load Pattern:</u> It sets the Revit load case name. Loads part of a load pattern that is not itself exported are not imported into Revit.
- <u>Coordinate System</u>: Joint loads and frame element concentrated loads defined in coordinate systems other than the local joint coordinate system or the model global coordinate system are not imported into Revit.
- Force X, Force Y, Force Z, Moment about X, Moment about Y, and Moment about Z: Set the values of Fx, Fy, Fz, Mx, My, Mz in Revit.





Ground displacement joint loads are not imported into Revit Structure.

Frame Element Loads

Frame element distributed loads are imported into Revit Structure as line loads. Distributed loads consisting of a sequence of trapezoidal loads are imported as multiple loads with one Revit line load for each trapezoidal segment. Not all force joint loads are imported: see Load Pattern and Coordinate System below. The following SAP2000 frame element load attributes are imported into Revit Structure:

- <u>Load Pattern:</u> It sets the Revit load case name. Loads part of a load pattern that is not itself exported are not imported into Revit.
- <u>Coordinate System</u>: Frame element distributed loads defined in coordinate systems other than the local joint coordinate system or the model global coordinate system are not imported into Revit.
- <u>Load Type, Direction and Load:</u> Set the values of Fx1, Fx2, Fy1, Fy2, Fz1, Fz2, Mx1, Mx2, My1, My1, My2, Mz1, and Mz2 in Revit. Projected load magnitudes are converted to absolute load magnitudes based on the geometry of the frame element.

Temperature, strain, target force and internal force frame element loads are not imported into Revit Structure.

Shell and Plane Element Loads

Shell element uniform, uniform to frame, and surface pressure loads and plane element surface pressure loads are imported into Revit Structure as area loads. Not all force joint loads are imported: see Load Pattern and Coordinate System below. The following SAP2000 shell and plane element loads attributes are imported into Revit Structure:

- <u>Load Pattern:</u> It sets the Revit load case name. Loads part of a load pattern that is not itself exported are not imported into Revit.
- <u>Coordinate System</u>: Shell and plane element distributed loads defined in coordinate systems other than the local joint coordinate system or the model global coordinate system are not imported into Revit.
- <u>Load Direction and Load</u>: Set the value of Fx1, Fy1, Fz1, in Revit. Projected load magnitudes are converted to absolute load magnitudes based on the geometry of the shell or plane element.

Shell and plane element temperature loads, shell element strain loads, plane element pore pressure loads are not imported into Revit Structure.





Load Patterns

SAP2000 load patterns with types corresponding to a predefined Revit Structure load case category are imported into Revit Structure as load cases. The following SAP2000 load pattern attributes are imported into Revit Structure:

- Load Pattern Name: The same name is used in Revit.
- <u>Load Case Type:</u> It sets the Revit load case nature and category. The mapping is shown in the following table:

SAP2000 Load Case Type	Revit Structure Load Case Category
Dead, Super Dead	Dead
Live, Reducible Live,	Live
Pattern Live	
Roof Live, Ice	Roof Live
Snow	Snow
Wind	Wind
Quake	Seismic
Temperature,	Temperature
temperature gradient	
Other	Not exported
Not listed above	Not exported

Load patterns with types that do not correspond to any predefined Revit Structure load case category are not imported into Revit Structure, and neither are any of their constituent loads.

Load Cases

If any SAP2000 static linear load case refers to more than one load pattern, than the static linear load cases are imported into Revit Structure as load combinations, in place of the SAP2000 load combinations. The following SAP2000 load case attributes are imported into Revit Structure:

- <u>Load Case Name</u>: The same name is used in Revit.
- <u>Load Patterns</u>: Set the list of Revit Structure load cases. Load patterns not imported are not included in the Revit list.
- <u>Load Pattern Factors</u>: Identical load case factors are used in Revit, unless the load pattern list includes load patterns that were not exported. Their factors are not imported into Revit.

SAP2000 load cases that are not static or are not linear are not imported into Revit Structure.





Load Combinations

If all the SAP2000 static linear load case each refer to a single load pattern, then the SAP2000 load combinations are exported as Revit Structure load combinations. When load combinations are exported, their following attributes are exported:

- Load Combination Name: The same name is used in Revit.
- <u>Load Cases</u>: Sets the list of Revit load cases. The Revit list is made of the load pattern names that each load case in the SAP2000 list refers to. Load patterns not imported are not included in the Revit list.
- <u>Load Case Factors</u>: If all the load cases in the list of load cases refer to their load patterns with a scale factor of 1, the same load case factors are used in Revit. If any load case refers to a load pattern with a scale factor other than 1, the Revit load case factors are adjusted accordingly. Scale factors for load patterns not imported are not included.





Procedures

Exporting from Revit Structure to create a new SAP2000 Model

IMPORTANT NOTE: CSiXRevit only exports the analytical models of Revit Structure elements. All the analytical models of all Revit Structure elements must be correctly connected to others to ensure the stability of the SAP2000 model generated.

The following steps describe how to export a Revit Structure analytical model into SAP2000:

- 1. With Revit Structure running, open a project you want to export.
- 2. From the Revit Structure menu, select Tools>External Tools>Export to Create New ETABS or SAP2000 Model.
- 3. CSiXRevit counts the objects in the Revit project and displays the Export to Create New ETABS or SAP2000 Model dialog:

Select Objects to Export to ETAB	
	S/SAP2000
📝 Grids (6)	No Point Loads
📝 Frames (58)	No Line Loads
📝 Walls (1)	🔄 No Area Loads
📝 Floor Slabs (2)	No Load Combos
🗌 No Footings	
Revit Structure Selected D	bjects Only

Select the types of elements to send to SAP2000. If you have selected some objects prior to starting the command and wish to only export those objects, check the corresponding box at the bottom of the dialog.

Once you have made your selections, click OK.





The Exporting to Create New ETABS or SAP 2000 Model message box is shown and displays the progress of the export:

Exporti	ng to Create New ETABS or SAP2000 Model
Fil Pr 1 1 1 1 1 1 1 1 1 1 1 1	e name = C:\Specifications\CSiXRevit\CSiXRevit Tickets\Tick ocessing(5375/5688) fotal Levels Processed(3/3) fotal Grids Processed(6/6) fotal Frames Processed(0/58) fotal Valls Processed(0/1) fotal Footings Processed(0/0) fotal Loads Cases Processed(8/10) fotal Joint Loads Processed(8/10) fotal Line Loads Processed(0/0) fotal Area Loads Processed(0/0) fotal Load Combos Processed(0/0)
	OK Cancel

- 4. Once the process has run its course, click OK. You are now asked to select a file name. The file will be given the extension .EXR.
- Start SAP2000 if it is not already running. If it is already running and you want to retain the changes you made to the current model, save the current model. SAP2000 always creates a new model when importing an .exr file.
- 6. Select a SAP2000 unit system. If any issues arise during the import part of the exchange, SAP2000 generates a log file in which the locations of the problematic objects are reported in meters if you select metric units, or in feet otherwise.
- From the menu, select File>Import>Revit Structure .exr File. The Import Revit Structure .exr file dialog is displayed. Click the "Select EXR File" button, and select the .exr file to import.





A summary of its contents is displayed:

Import Revit Structure exr file	
Select EXR File	dels\AA Revit Structure analysis start comp beams EXR
Add Sections File	AISC13.PRO
245 Frame Elements	
✓ 24 Walls	
General Sectors	
🗖 No Openings	
9 Point Loads	
G Line Loads	
🔲 3 Area Loads	
Import In SAP2000	

If any of the framing member family type names in the Revit Structure project do not match any of the SAP2000 section profile names listed in AISC13.pro, the dialog includes a table listing all the unrecognized types:

Import Revit Structure exr file			×
Select EXR File	:\Samples\Amelia ET.	ABS\model exported from R	evit.EXR
Add Sections File	AISC13.PRO		
928 Frame Elements	Revit Type	SAP2000 Profile	
🗖 No Walls	C130X10	C10X15.3	•
224 Floors	C150X12	C15X33.9	•
I Openings	C200X17	C10X15.3	•
196 Point Loads	C230X20	C10X15.3	-
✓ 1697 Line Loads	C250X30	C10X15.3	-
324 Area Loads	HS152X152X13	HSS1.660X.140	-
	HS152X152X9.5	HSS1.660X.140	-
Import In SAP2000	HS178X178X13	HSS1.660X.140	
Loading another sections file	may help.		

The default SAP2000 profile selected in the right column for each unrecognized type in the left column is the closest alphabetical match in AISC13.pro (or AISC13M.pro depending on the unit system in use when the import began).





8. Click the "Add Sections File" button to load additional SAP2000 section properties databases (.PRO file). Alternately, you can directly edit the default filename in the field next to the button, pressing the TAB key when you are done. The Revit types that now have a name match – like C250X30 in the example above – are removed from the list:

Import Revit Structure exr file		<u> </u>	
Select EXR File):\Samples\Amelia ET/ AISC13M.PRO	ABS\model exported from Revit.EXR	
928 Frame Elements	Revit Type	SAP2000 Profile	
🗖 No Walls	C130X10	C130X10.4 💌	
224 Floors	C150X12	C150X12.2 🔹	
I Openings	C200X17	C200X17.1	
✓ 196 Point Loads	C230X20	C230X22 🗸	
✓ 1697 Line Loads	HS152X152X13	HSS101.6X101.6X1 💌	
324 Area Loads	HS152X152X9.5	HSS101.6X101.6X1 💌	
	HS178X178X13	HSS101.6X101.6X1 💌	
Import In SAP2000	HS178X178X9.5	HSS101.6X101.6X1 💌 🖵	

9. For each unknown Revit type in the left column, if the corresponding SAP2000 section profile in the right column is not the right one, choose another one from the drop-down list of predefined profiles:

Select EXR File	:\Samples\Amelia ET.	ABS\model exported from Revit.EX
Add Sections File	AISC13M.PRO	
928 Frame Elements	Revit Type	SAP2000 Profile
No Walls	C130X10	C130X10.4 💌
224 Floors	C150X12	C150X12.2 💌
I Openings	C200X17	C200X17.1 💌
196 Point Loads	C230X20	C230X22 💌
1697 Line Loads	HS152X152X13	HSS152.4X152.4X12.7 -
324 Area Loads	HS152X152X9.5	HSS152.4X152.4X12.7
	HS178X178X13	HSS152.4X152.4X15.5
	LIC170V170V0 5	HSS152.4X152.4X4.8





"None" SAP properties are always available at the top of the list.

SAP2000 saves your choices in a file which has an .EXRMap extension. Importing the same Revit project again restores your choices.

- Select what to import by checking or unchecking the relevant check boxes. (When checking Area Loads, you will receive a reminder that Area Loads cannot be imported into the current version of SAP2000.)
- 11. Click the **Import in SAP2000** button.

After a few moments, SAP2000 displays the newly imported model.

12. If any issues arise during the import part of the exchange, you will be prompted to review the log file. Please do.





Importing from SAP2000 to create a new Revit Structure Project

The following steps describe how to export a SAP2000 model to create a new Revit Structure project:

- 1. With SAP2000 running, open a model you want to export.
- 2. Select File>Export>**Revit Structure .exr File.** The Export Revit Structure .exr File dialog is displayed. It includes a summary of the model contents on the left side and a table with level names on the right side:

116 Frame Elements		At or Below	Level Name	Elevation							
No Cable Elements		56.54	Elev. 56.5'	56.54							
No Walls		56.26	Elev. 56.0'	55.98							
 ✓ 11 Floors ✓ 26 Point Loads ✓ 80 Line Loads 		53.62	Elev. 51.3'	51.26							
	<u>र</u> र	48.26 43.54 41.52	Elev. 45.3' Elev. 41.8' Elev. 41.2'	45.26 41.82 41.23							
								40.05	Elev. 38.9'	38.87	-
								38.60	Elev. 38.3'	38.33	
I Metric		35.19	Elev. 32.1'	32.05	-						
		29.30	Elev. 26.6'	26.55	-						
Save As Create EXR File	C:\F	Revit Models\\	Stadium\BW bowl1	3 part with diap	hra						

Unlike Revit, which is geared towards building structures, SAP2000, which is a general purpose analysis program, does not include the concept of story levels. Therefore Revit levels need to be created when a SAP2000 model is imported into Revit. The dialog gives you control over which levels are created, their names, their elevations, and how exported SAP2000 elements are assigned to them in Revit.





3. If the joints in the SAP2000 model occur at a large number of different z elevations, you will probably want to create Revit levels only for a small subset of these elevations. In that case, uncheck the check box at the top of the levels table. It unchecks all the levels at once:

116 Frame Elements	At or Below	Level Name	Elevation
No Cable Elements		Elev. 56.5'	56.54
No Walls		Elev. 56.0'	55.98
11 Floors		Elev. 51.3'	51.26
✓ 26 Point Loads		Elev. 45.3'	45.26
Z 80 Line Loads		Elev. 41.8'	41.82
Ne Asea Leads		Elev. 41.2'	41.23
No Area Loads		Elev. 38.9'	38.87
		Elev. 38.3'	38.33
Metric		Elev. 32.1'	32.05
		Elev. 26.6'	26.55
Save As Create EXR File	C:\Revit Models\	Stadium\BW bowl1	3 part with diap

4. Check the box next to each story level you want created. As you check levels, SAP2000 computes default cutoff elevations and displays them in the "At or Below" field. SAP2000 shell elements are imported into Revit as walls, floors, or ramps and SAP2000 frame and cable elements are imported into Revit as columns, beams or braces. The top and bottom levels of these Revit walls, columns and braces, and the reference levels of these beams and slabs are assigned based on the relationship between the level cutoff elevations and the z-coordinates of the joints defining the original SAP2000 elements.

You can override any cutoff elevation by typing over a new elevation and pressing the TAB key – as long as you do not set it lower than the corresponding level elevation, or higher than the elevation of the next level to be created above.





Likewise, you can rename any level by typing a new name, and change its elevation by typing a new elevation:

116 Frame Elements		At or Below	Level Name	Elevation
No Cable Elements		56.54	Roof	56.54
No Walls			Elev. 56.0'	55.98
1 Floors	◄	53.90	Club Level	51.26
6 Point Loads			Elev. 45.3'	45.26
Oline Loads			Elev. 41.8'	41.82
- Area Londo			Elev. 41.2'	41.23
o Relid Elemente	•	45.07	Upper Reserve	38.87
Metric			Elev. 38.3'	38.33
	~	35.46	Lower Reserve	32.05
			Elev. 26.6'	26.55

SAP2000 saves your level data in a file which has an .EXRMap extension. Exporting the same SAP20000 model again restores your level data.

- 5. Select what to export by checking or unchecking the relevant check boxes.
- 6. The Metric check box controls the units in which level elevations are displayed, the family names of the concrete section types created in Revit, and the units of the log file.
- 7. By default, the .exr file written is written in the same folder as the model and its name is the name of the model with an .EXR extension. To save the .exr file in a different folder or under a different name, click the Save As... button. Alternately, you can directly edit the default filename in the field next to the button, pressing the TAB key when you are done.
- 8. Click the Create EXR File button.
- 9. If any issues arise during the export part of the exchange, you will be prompted to review the log file. Please take a moment to do so.




You are now ready to import the .exr file in Revit Structure. You import an .exr file written by SAP2000 exactly like an .exr file written by ETABS:

- 10. Start Revit Structure.
- 11. Create a new Revit Structure project. Note while it isn't required, the import will come in much faster if your Revit Structure template already contains all the column, beam, brace, slab and wall family types you would like SAP2000 sections to map to.
- 12. From the menu, select Add-Ins>External Tools>Import to Create New Revit Structure Project from ETABS or SAP2000. Select the .exr file to import. CSiXRevit attempts to locate and load family types that are not already loaded.
- 13. The Import to Create New Revit Structure Project from ETABS/SAP2000 dialog is displayed:

Velect Objects Image: Grid Lines (28) Image: Prames (596) Line Loads	Column Columns present in ETABS/SAP2000 model = 212 Columns present in Revit Structure Project = 0
Image: Grid Lines (28) Point Loads Image: Frames (596) Line Loads	Columns present in ETABS/SAP2000 model = 212 Columns present in Revit Structure Project = 0
Frames (596)	
	Delete columns in project and create new instances which were meshed in ETABS model
Valls (18) Area Loads (5)	
V Floor Slabs (5) 📃 Load Combos	Structural Framing
📝 Openings (12)	Beam/Braces present in ETABS/SAP2000 model = 384 Beam/Braces present in Revit Structure Project = 0
	Delete beams/braces in project and create new instances which were meshed in ETABS model
Janning Ontions	
	Floor
Frame Sections Wall Sections	Hoors present in ETABS/SAP2000 model = 5 Floors present in Revit Structure Project = 0
Floor Sections Objects	Delete floors in project and create new instances which were meshed in ETABS model
nformation to Update	Wall
C Locations and Releases	Walls present in ETABS/SAP2000 model = 18 Walls present in Revit Structure Project = 0
O Designs and Magnitudes	Delete Walls in project and create new instances which were meshed in ETABS model
Ø Both	

On the left side, you can control the types of SAP2000 elements to import into the new Revit project.





Under Mapping Options, click the "Frame Sections" button, to see the Frame Section Mapping dialog:

450			_	
450mm	Concrete-Round-Column	450mm	_	
750mm	Concrete-Round-Column	750mm		
HSS114.3X8.6	Pipe-Column	HSS114.3X8.6 356x368x129UC		
UC356X368X129	UC-Universal Column-Column			
300 x 600mm	Concrete-Rectangular Beam	300 x 600mm		
Seam Mapping	Devit Oraclas Fresh News	De la Carata a Facta Tara	_	
300 x 600mm	Concrete-Rectangular Beam	300 x 600mm		
400 x 800mm	Concrete-Rectangular Beam	400 x 800mm	-	
600 x 900	Concrete-Rectangular Beam	600 x 900		
HSS114.3X8.6	HSS-Round Structural Tubing	HSS114.3X8.6		
•		,		
Brace Mapping				
ETABS/SAP2000 Section	Revit Structure Family Name	Revit Structure Family Type		
HSS114.3X8.6	HSS-Round Structural Tubing	HSS114.3X8.6		

Changes to the mapping of SAP2000 sections to Revit sections can be made here. All Revit column beam and brace families currently loaded are displayed in the drop down lists.





Clicking the "Floor Sections" button displays the "Floor Section Mapping" dialog:

Floor	Section	Mapping		
		ETABS/SAP2000 Section	Revit Structure Section	l
	•	Deck1	Create Revit Structure equivalent	l
		ОК	Cancel	

Changes to the mapping of SAP2000 floor sections to Revit sections can be made here. All Revit floor families currently loaded are displayed in the drop down lists.

Wall Sect	on Mapping		
			_
	ETABS/SAP2000 Section	Revit Structure Section	
- F	Generic - 12"	Generic - 12"	-
	Generic - 6"	Generic - 6"	-
	WALL2	Create Revit Structure equivalent	•
	ОК	Cancel	
			_

Clicking the "Wall Sections" button displays the "Wall Section Mapping" dialog:





Changes to the mapping of SAP2000 wall sections to Revit sections can be made here. All Revit wall families currently loaded are displayed in the drop down lists.

- 14. Once you have set up all of your mapping, select the **OK** button. After a few moments, your Revit project is displayed.
- 15. If any issues arise during the import part of the exchange, you will be prompted to review the log file. Please take a moment to do so.





Known Limitations with CSiXRevit and SAP2000

- 1. Windows with UAC: With strict UAC (User Account Control), users must "Run as Administrator" (for SAP2000.exe and Revit.exe). If Revit Structure is not run as administrator, it is possible CSiXRevit will not be able to open the .log file. In this case, CSiXRevit will not write any warnings to the log file but all warning messages will be displayed on the screen. Directly sending data to SAP2000 may not work if Revit Structure is not run as administrator.
- 2. In the case of shell and plane elements that are neither vertical nor horizontal, floors with a slope are created in Revit. While their slope is initially set correctly, Revit subsequently resets it to a different value. The correct slope is available as a shared parameter named "Computed slope" and you need to reset the slope of the floor to this parameter value.
- 3. Materials imported into Revit Structure from SAP2000 may not always be properly mapped or the property values may not always be properly transferred. For this reason, material mapping and material property values should always be carefully checked in Revit Structure after importing from SAP2000.
- 4. See other limitations described in the previous sections for SAP2000.

